



Electronic Service Manuals

This electronic document is provided as a service to our customers. We do not create the contents of the information contained in this document. Should you have detailed questions pertaining to the information contained in this document, you may contact Michco, or the manufacturer which provided the original information in this electronic deliverable. Michco's only part in this electronic deliverable was the electronic assembly process. By providing this manual on line we are not guaranteeing parts availability.

You may contact Michco through the following methods:

Phone (517) 484-9312 or (800) 331-3339

2011 N. High St. -- Lansing, Michigan -- 48906

Fax: (517) 484-9836

Email: CustServe@Michco.com

Web site: www.Michco.Com

Parts Web site: www.FloorMachineParts.Com

Order Parts on Line at:

www.FloorMachineParts.Com

Directly to Parts & Service:

By Email: **Shop@Michco.com**

By Fax: (517) 702-2041

By Voice: Use numbers above.

Serving the Cleaning Industry Since 1922

Notice: All copyrighted material remains property of original owners, all trademarks are property of respective owners. Manuals are subject to Manufacturer's reproduction limitations. Originals or reproductions were provided by manufacturers through a request. We make no warranty as to the correctness of information provided in this document and you assume all risk. By placing these manuals on line we are not declaring our corporation to be an manufacturer authorized dealer or provider, please check our web site for authorized manufacturers we represent.

American-Lincoln®

3366XP, 4366XP



PARTS LIST

**American-Lincoln Models 579-546, 579-547, 579-548, 579-549, 579-550, 579-551
579-546CE, 579-548CE, 579-550CE, 579-551CE**

After Serial Number 586065


TABLE OF CONTENTS**3366XP, 4366XP****3**

DESCRIPTION	PAGE
Frame, Broom Doors, & Flaps	4-5
Main Broom Assembly	6-7
Main Broom Lift Mechanism.....	8-9
Side Broom Assembly	10-11
Operator Compartment	12-13
Control Panel & Horn	14-15
Hopper Lid & Filter System	16-17
Hopper Lift System (Variable Dump).....	18-19
Hopper Lift System (Low Dump).....	20-21
Steering Gear & Rear Drive System	22-23
Forward/Reverse Assembly (Gasoline/LPG/Diesel)	24-25
Forward/Reverse Control (Gasoline & LPG Only)	26-27
Forward/Reverse Control (Diesel Only)	28-31
Front Wheel & Brake Assembly	32-33
Brake Control Linkage.....	34-35
Impeller & Fittings	36-37
Control Valve & Fittings (Variable Dump).....	38-39
Control Valve & Fittings (Low Dump)	40-41
Rear Drive Motor & Fittings.....	42
Main Broom Motor & Fittings.....	43
Side Broom Motor & Fittings	44
Lift, Rotation & Dump Cylinders w/ Fittings (Variable Dump).....	45
Dump Cylinders w/ Fittings (Low Dump).....	46
Lift Cylinder Lock-out Valve & Fittings.....	47
Auxiliary Manifold & Fittings.....	48
Return Manifold Assembly (Low Dump)	49
Return Manifold Assembly (Variable Dump)	50-51
Hydraulic Reservoir & Fittings.....	52-53
Engine Cover	54-55
Engine Access Door.....	56-57
GM 3.0 Liter - Gas & LP Engines (Mounting Brackets).....	58-59
GM 3.0 Liter - Gas Engine (Fan, Air Intake & Radiator Hoses).....	60-61
GM 3.0 Liter - LP Engine (Fan, Air Intake/Radiator Hoses)	62-63
GM 3.0 Liter - Gas & LP Engines (Exhaust System)	64-65
GM 3.0 Liter - Gas Engine (Fuel System)	66-69
Radiator Assembly - GM 3.0 Liter Engine (Gasoline & LPG).....	70-71
LP Tank System	72-73
Air Cleaner Assembly (Gasoline/LPG/Diesel).....	74-75
Mitsubishi SQ2 - Diesel Engine (Fan, Brackets, Throttle).....	76-77
Mitsubishi SQ2 - Diesel Engine (Exhaust System)	78-79
Mitsubishi SQ2 - Diesel Engine (Fuel System)	80-81
Radiator Assembly (Diesel).....	82-83
Fuel Tank (Diesel)	84-85
CE Kit (3366XP only)	86-87
Decals	88-89
Instrument Panel.....	90-91
Hydraulic Hose System (Variable Dump).....	92-93
Hydraulic Hose System (Variable & Low Dump).....	94-95
Hydraulic Hose System (Low Dump).....	96-97
Harness Routing (Gasoline/LPG/Diesel).....	98-99
Wiring Diagram	100

WHEN ORDERING PARTS

- * Use the 8-10 digit numbers from the "Ref. No." columns in this parts list.
- * Specify the model and serial number of the machine.
- * Use the space below to record the model and serial number for future reference.

Model _____ Serial No. _____



		FRAME, BROOM DOORS, & FLAPS			
08-2		3366XP, 4366XP			5


Item	Ref. No.	Qty	Description
1	8-27-07124	1	Frame
2	2-00-00233	2	Screw, 3/8-16 x 1.0 HHC
3	2-00-02310	2	Lock Washer, 3/8 Helical Spring
4	2-00-00240	3	Screw, 1/2-13 x 1.25 HHC
5	2-00-00596	3	Nut, 1/2-13 x .750 x .437 Hex
6	8-25-08172	1	Flap, Rear Inside BC Frame
7#	8-19-08073	1	Door, LH Broom Chamber
8#	8-19-08072	1	Door, RH Broom Chamber
9	8-25-08185	2	Flap, Outer BC Door
10	8-13-07105	2	Clamp, Outer BC Door Flap
11	2-00-00205	16	Screw, 1/4-20 x 3/4 HHC
12	2-00-00518	17	Lock Washer, 1/4 Helical Spring
13	2-00-00594	5	Nut, 1/4-20 x .437 x .218 Hex
14	8-25-08174	2	Flap, Wheel Well
15	8-25-08184	2	Flap, Inner Broom Door
16	2-00-03702	18	Flat Washer, .625 x .281 x .062
17	2-00-01676	18	Flat Washer, 1.062 x .265 x .062
18	8-13-07100	1	Clamp, BC Inner Rear Flap
19	8-25-08173	1	Flap, Rear Outside BC Frame
20	7-41-00065	2	Latch, Broom Door
23	8-68-05073	2	Seal, Main Broom Chamber
24	8-13-07097	1	Clamp, Outer BC Rear Flap
25	2-00-00402	2	Flat Washer, .750 x .390 x .093
26	8-13-07098	2	Clamp, Wheel Well Flap
27	2-00-04877	6	Screw, 1/4-20 x 1.0
28	8-52-00156	1	Front Skirt
29	8-13-07104	2	Clamp, Inner Broom Door Flap
30	8-32-00043	2	Hinge, Plated
31	2-00-00078	8	Screw, 1/4-20 x 1.0 HHC
32	2-00-02196	9	Carriage Bolt, 1/4-20 x 1.0
33	2-00-00641	36	Nut, 1/4-20 Fiber Lock
34	2-00-02312	3	Lock Washer, 1/2 Helical Spring
35	2-00-04159	3	Flat Washer, 9/16 I.D.
36	2-00-03575	18	Carriage Bolt, 1/4-20 x 3/4
37	8-41-00047	2	Tab, Broom Door Latch

= Revised or new since last update

MAIN BROOM ASSEMBLY

6

3366XP, 4366XP




MAIN BROOM ASSEMBLY			
3366XP, 4366XP			7

Item	Ref. No.	Qty	Description
1	8-16-00039	1	Broom Arm Weldment
2	2-00-04886	2	Screw, 3/8-16 x 1/2 HSHC
3	8-33-09090	1	Idle, Main Broom
4	2-00-04889	1	Ball Bearing
5	2-00-04890	1	Retaining Ring, 2.437 Int.
6	8-75-01157	1	Flat Washer, 3/4
7	2-00-00522	1	Lock Washer, 3/4 Helical Spring
8	2-00-04887	1	Screw, 3/4-10 x 1.25 HHC
9	8-58-05160	1	Plate, Locking Hub
10	2-00-00232	4	Screw, 3/8-16 x 3/4 HHC
11	2-00-02310	6	Lock Washer, 3/8 Helical Spring
12	8-33-09046-1	1	Drive Hub
13	8-16-00041	1	Arm, Drive Broom
14	2-00-03039	3	Screw, 1/4-20 x .625 HSHC
15	2-00-00518	6	Lock Washer, 1/4 Helical Spring
16	2-00-03838	1	Woodruff Key, 1/4 x 1 (#15)
17	0882-040	REF	Hydraulic Motor
18	2-00-00585	4	Nut, Hex 5/16-18 x .500 x .265
19	2-00-00530	4	Lock Washer, 5/16 Helical Spring
20	2-00-00409	4	Flat Washer, .687 x .343 x .062
21	8-21-04048	2	Edging
22	2-00-03997	2	Flange Bearing, 3.750 x 1.0
23	2-00-00196	4	Carriage Bolt, 5/16-18 x 1.0
24	2-00-00233	2	Screw, 3/8-16 x 1.0 HHC
25	8-29-00220	4	Gasket, Broom Chamber
26	REF	1	Main Broom
27	8-03-04281	1	Lift Frame, Main Broom
28	2-00-04885	1	Elbow Fitting - 90° St. Thd.
29	2-00-04895	1	Straight Fitting - SAE #4 to ORS #4

MAIN BROOM LIFT MECHANISM


8

3366XP, 4366XP




MAIN BROOM LIFT MECHANISM			
3366XP, 4366XP			9

Item	Ref. No.	Qty	Description
1	8-08-00645	1	Bracket, Main Broom Pivot
3	8-66-00161	1	Rod, Linkage (Main Broom)
4	2-00-00432	3	Flat Washer, 3/4 I.D.
5	8-70-05284	1	Shaft
6	2-00-02558	1	Lubrication Fitting, 45° 1/8 NPT
7	8-16-00035	1	Pivot Block
8	2-00-00234	2	Screw, 3/8-16 x 1.50 HHC
9	8-75-01177	1	Pivot Tube Spacer
10	2-95-04182	2	Nut, 3/8-16 Fiber Insert Hex
11	8-16-00034	1	Lever
12	8-39-00003	1	Knob
13	2-00-02436	1	Cotter Pin, 1.500 x 1.875
14	2-00-00530	2	Lock Washer, 5/16 Helical Spring
15	2-00-00585	1	Nut, 5/16-18 x .500 x .265 Hex
16	8-66-00141	1	Rod End
17	2-00-00591	1	Nut, 1/2-20 x .750 x .312 Hex Jam
18	8-66-00150	1	Rod, Control Rod Lift Linkage
19	8-66-00144	1	"MPB" Rod End # WF-8-32
20	8-55-08101	1	Clevis Pin #1/2-1.75 - E&E
21	8-16-00037	1	Lift Linkage
22	2-00-04891	1	Wing Nut, 3/4-10 Thread
23	8-39-00011	1	Torque Knob
24	8-75-01180	1	Spacer
25	8-55-08099	1	Pivot Pin
26	8-75-01178	2	Spacer, .78 x .97
27	8-16-00038	1	Pivot Shaft
28	2-00-00518	3	Lock Washer, 1/4 Helical Spring
29	2-00-00221	3	Screw, 1/4-20 x 3/4 HHC
30	2-00-00208	2	Screw, 5/16-18 x 3/4



SIDE BROOM ASSEMBLY			
3366XP, 4366XP			11


Item	Ref. No.	Qty	Description
1	8-03-04282	1	Arm, RH Side Broom
2	2-00-04914	1	Screw, 1/2-13 x 4.25 HHC
3	8-08-00725	1	Bracket, Side Broom Adjustment
4	2-00-00233	9	Screw, 3/8-16 x 1.0 HHC
5	2-00-04159	3	Flat Washer, 1.375 x .562 x .109
6	8-08-00726	1	Bracket, Motor Mounting
7	2-00-00208	2	Screw, 5/16-18 x 3/4 HHC
8	2-00-02310	9	Lock Washer, 3/8 Helical Spring
9	2-00-00241	3	Screw, 1/2-13 x 1.75 HHC
10	8-10-00028	1	Cable, RH Side Broom
11	2-00-02708	1	Screw, 5/16-18 x 1.0 HHC
12	2-00-00209	1	Screw, 3/8-16 x 1.25 HHC
13	2-00-00644	2	Nut, 5/16-18 Fiber Insert Hex
14	2-00-04936	2	Nut, 1/2-13 Fiber Insert Hex
15	0882-047	1	Motor, Side Broom
15a	2-00-00722	Ref.	Woodruff Key, 1/4 x 1.0 (#15)
16	2-00-00584	2	Nut, 3/8-16 Hex
17	2-00-04801	6	Flat Washer, 3/8
18	2-00-01490	1	Screw, 1/4-20 x .875 HHC
19	2-00-00518	3	Lock Washer, 1/4 Helical Spring
20	8-08-03211	1	Side Broom, Nylon
21	8-25-06008	1	Flange, Side Broom
22	2-00-00218	3	Screw, 5/16-18 x 2.0
23	2-00-00409	3	Flat Washer, .687 x .343 x .062
24	2-00-00530	5	Lock Washer, 5/16 Helical Spring
25	2-00-00585	5	Nut, 5/16 - 18 x .500 x .265 Hex
26	2-00-04926	2	Fitting, 90° Elbow
27	2-00-04915	1	Reducer Fitting
39	2-00-00584	2	Nut, 3/8-16 Hex
28	8-08-00646	1	Bracket, Side Broom Pivot
29	8-70-05285	1	Shaft, RH Broom Pivot
30	2-00-02312	3	Lock Washer, 1/2 I.D.
31	2-00-00596	3	Nut, 1/2-13 Hex
32	2-00-00221	2	Screw, 1/4-20 x 3/4 HHC
33	8-57-05021	1	Block, Side Broom Pivot
34	2-00-02558	1	Lubrication Fitting, 45° 1/8 NPT
35	8-16-00034	1	Lever
36	2-00-00234	1	Screw, 3/8-16 x 1.50 HHC
37	2-95-04182	1	Nut, 3/8-16 Fiber Insert Hex
38	8-39-00003	1	Knob
44	8-30-05166	1	Guard, Side Broom
46	2-00-00207	1	Screw, 5/16-18 x 1.25 HHC



OPERATOR COMPARTMENT			
08-2	3366XP, 4366XP		13


Item	Ref. No.	Qty	Description
1	8-89-04014	9	Weights
2	2-00-00427	2	Flat Washer, .875 x .515 x .062
3	2-00-04936	1	Nut, 1/2-13 Fiber Insert Hex
4	7-23-03113	3	Fastener, 1/4 Turn
5	8-08-00816	1	Bracket, Switch
6	2-00-00407	1	Flat Washer, .562 x .265 x .062
7	2-00-00518	3	Lock Washer, 1/4 Helical Spring
8	2-00-00221	9	Screw, 1/4-20 x 3/4 HHC
9	2-00-00602	2	Nut, #8-32 MS Hex
10	2-00-00529	2	Lock Washer, #8 Helical Spring
11	8-82-00058	1	Switch, Hopper
12	2-00-03061	2	Screw, #10-24 x 1/2 THM
13	8-52-00140	1	Panel, Seat Deck
14	2-00-00518	4	Lock Washer, 1/4
15	2-00-00183	4	Screw, 1/4-20 x 3/4 THM
16	2-00-02312	1	Lock Washer, 1/2 Helical Spring
17	2-00-00239	1	Screw, 1/2-13 x 1.0 HHC
18	2-00-03575	4	Carriage Bolt, 1/4-20 x 3/4
19	8-16-07334	1	Cover
20	7-23-03106	3	Retainer Washer
21	8-19-08042	1	Door, Battery Access
22	2-00-00594	9	Nut, 1/4-20 x .437 x .218 Hex
23	8-33-05112	1	Operator's Compartment
24	8-08-00588	1	Bracket, Battery Hold-Down
25	0875-008	1	Battery (Gas/LP)
	0875-057		Battery (Diesel)
26	7-23-03108	3	Receptacle
27	8-08-07045	4	Edging
28	2-00-00203	4	Screw, 1/4-20 x 1.50 HHC
29	8-65-00024	2	Clamp, Hose
30	8-75-01116	4	Spacer, .312 x .250 x .875
32	2-00-04914	1	Screw, 1/2-13 x 4.25 HHC
33#	8-69-00019	1	Seat, Suspension
*#	2-00-00409	4	Wshr, Flat .688 x .344 x .063 STL
*#	2-00-00530	4	Lk Wash 5/16 Med Sec SPL ZN
*#	2-00-00585	4	Nut, Hex-Fin .31-18 ZN
34#	8-03-04320	1	Arm Rest Kit (RH + LH)

= Revised or new since last update




CONTROL PANEL & HORN			
3366XP, 4366XP			15

Item	Ref. No.	Qty	Description
1	8-33-05111	1	Instrument Housing
2	2-00-00407	12	Flat Washer, .562 x .265 x .062
3	8-13-07087	2	Clip
4	2-00-00221	19	Screw, 1/4-20 x 3/4 HHC
5	8-52-00157	1	Kickboard Panel
6	2-00-00518	17	Lock Washer, Helical Spring 1/4 Med
7	8-58-05224	1	Face Plate, Instrument Compartment
8	8-58-05265	1	Face Plate, MB Control/Throttle (Diesel)
	8-58-05291	1	Face Plate, MB Control/Throttle (Gas/LP)
9	2-00-03061	3	Screw, #10-24 x 1/2 THM
10	2-00-00605	9	Nut, Hex MS #10-24 x .375 x .125
11	2-00-00519	9	Lock Washer, #10 Helical Spring
12	8-58-05222	1	Backing Plate, Brush Control Lever
13	8-32-09013	1	Horn
14	2-00-00208	1	Screw, 5/16-18 x 3/4 HHC
15	2-00-00530	1	Lock Washer, 5/16 Helical Spring
16	2-00-00585	1	Nut, 5/16-18 x .500 x .265 Hex
17	2-00-00686	1	Wrench, 3/4-9/16
18	2-00-03466	13	Screw, #10-16 x 1/2 T/F RH
19	2-00-04794	2	Screw, #10-24 x .625
20	2-00-00594	8	Nut, 1/4-20 x .437 x .218 Hex
21	2-00-00426	3	Flat Washer, .500 x .218 x .062
22	7-39-00017	1	Knob (Diesel)
24	8-08-00752	1	Bracket
25	2-00-01246	4	Nut, 10-24 Fiber Insert Hex
26	7-14-07006	1	Clevis Assembly
27	8-41-05074	1	Throttle Lever (Diesel)
28	2-00-01246	4	Nut, Hex #10-24 Fiber Lock
29	7-25-02050	1	Rod End (Diesel)
30	2-00-00626	1	Nut, #10-32 Hex
31	2-00-00633	1	Nut, 1/4-18 Fiber Lock
32	2-00-03702	2	Flat Washer, .625 x .281 x .062
33	8-13-07094	1	Clamp
34	8-08-00735	1	Bracket, Cable
35	8-82-00074	1	Switch Body & Actuator-1 piece (Gas/LP)
36	7-11-04080	1	Check Engine Light (MIL)




HOPPER, LID & FILTER SYSTEM			
07-6	3366XP, 4366XP		17

Item	Ref. No.	Qty	Description
1	8-16-07320	1	Hopper Lid (Lower)
2	2-00-04667	11	Screw, 3/8-16 x 1.25 BHS
3	2-00-02310	11	Lock Washer, 3/8 Helical Spring
4	8-75-01187	2	Spacer
5	8-16-07319	1	Cover (Upper)
6	8-41-00044	2	Latch, Low Profile Push Button
7	56001841	2	Scr, Soc Set lock 1/4-20 x .25
8	8-89-04019	2	Shaker Weight
9	0860-623	2	Shaker Motor
10	8-80-05032	1	Stud, Latch Arm
11	2-00-02371	2	Nut, 1/2-13 x .750 x .312 Hex Jam
12	8-66-00156	4	Rod, Rocker Pivot
13	8-58-05285	2	Plate, Rocker
14	8-41-00042	2	Latch, Shaker Frame
15	8-50-05056	8	Pad, Rocker Plate
16	2-00-00407	27	Flat Washer, .562 x .274 x .062
17	2-00-00641	24	Nut, 1/4-20 Hex Fiber Insert
18	8-27-07094	2	Shaker Frame
19	8-24-04123-1	2	Panel Filter
	8-24-04123-2		POLY Panel Filter Option
20	2-00-00221	13	Screw, 1/4-20 x 3/4 HHC
21	2-00-00518	12	Lock Washer, 1/4 Helical Spring
22	8-30-08026	1	Panel, Air Flow Deflector
23	8-21-04040	1	Edging, Right Side Support
24	7-23-03056	2	Nut
25	8-08-00671	2	Bracket, Hopper Stop
26	2-00-00402	7	Flat Washer, .750 x .390 x .093
27	8-08-00701	2	Bracket, Frame Lock
28	2-00-04880	4	Screw, 1/4-20 x 3/4 BHS
30	8-32-06096	1	Hopper
31	8-13-07101	2	Clamp, Hopper Side Flap
32	8-25-08180	2	Flap, Hopper Side
33	2-00-01246	4	Nut, 10-24 Fiber Lock
34	2-00-04794	4	Screw, 10-24 x .625 BHS
35	8-25-08179	1	Flap, Primary Deflector
36	8-79-00111	1	Strap, Primary Deflector Flap
37	2-00-00208	20	Screw, 1/4-18 x 3/4 HHC
38	2-00-00530	12	Lock Washer, 5/16 Helical Spring
39	8-13-07084	6	Clamp, Bottom Hopper Flap
40	8-25-08177	6	Flap, Upper Hopper
	8-25-08178	6	Flap, Lower Hopper
	0860-545	1	Kit, Upper & Lower Flaps
41	2-00-00220	3	Screw, 1/4-20 x .625 HHC
42	8-58-05237	1	Plate, Blower Mating
43	8-08-00692	1	Bracket, RH Frame Mounting
44	8-08-00690	1	Bracket, Center Frame Mounting
45	8-08-00691	1	Bracket, LH Frame Mounting
46	2-00-00409	4	Flat Washer, .687 x .343 x .062
47	2-00-00644	8	Nut, 5/16-18 Fiber Insert Hex
48	7-15-01022	4	Setscrew Collar, .750 x .378 x .375
49	8-16-07406	2	Cover, Shaker Motor
51	3-73-00060	24	Gasket, Bulb Seal
53	8-08-00668	2	Bracket, Hopper Lid Latch
54	2-00-02360	4	Nut, 3/8-16 Hex
55	8-29-00183	1	Gasket, Blower
56	2-00-00234	1	Screw, 3/8-16
57	8-25-08228	1	Flap, Hopper Vac Chamber
58	8-79-00130	1	Strap, Hopper Vac Chamber Flap
59	2-00-02708	2	Screw, 5/16-18 x 1.0 Hex Head
60	2-00-00641	4	Nut, 1/4-20 Fiber Insert




HOPPER LIFT SYSTEM (VARIABLE DUMP)			
3366XP, 4366XP			19

Item	Ref. No.	Qty	Description
1	8-55-08105	1	Hopper Dump Pin
2	2-00-00518	7	Lock Washer, Helical Spring 1/4 Med
3	2-00-00221	7	Screw, 1/4 - 20 x .750 HHC
4	8-55-08104	2	Hopper Pivot Pin
5	8-13-07103	2	Pivot Pin Half Clamp
6	8-03-04242	1	Arm Pivot Bracket Assembly
7	2-00-02310	12	Lock Washer, Helical Spring 3/8 Med
8	2-00-00234	8	Screw, 3/8 - 16 x 1.000 HHC
9	8-55-08102	4	Pin (Upper)
10	2-00-02558	4	Lubrication Fitting, 45° 1/8 NPT
11	2-00-04159	8	Flat Washer, 1.375 x .562 x .109
12	2-00-02312	8	Lock Washer, Helical Spring 1/2 Med
13	2-00-01254	6	Screw, 1/2 - 13 x 1.500 HHC
14	8-55-08107	2	Pin (Arm Pivot)
15	2-00-04893	2	Sleeve Bearing, 2.005 x 1.503 x 2.000
16	8-17-05029	2	Lift Cylinder
	0880-449	2	Seal Kit for Lift Cylinder
17	8-03-04246	2	Lower Arm
18	2-00-04894	2	Sleeve Bearing, 1.254 x 1.003 x 2.500
19	8-14-01010	1	Clevis, Dump Cylinder
20	2-00-00519	5	Lock Washer, Helical Spring #10 Med
21	8-82-00050	1	Switch Lift Arm Lockout
22	2-00-04378	2	Clip, .281
23	2-00-00056	3	Screw, #10 - 24 x .750 RHM
24	2-00-02371	2	Nut, Hex Hvy. Jam 1/2 - 13 x .875 x .296
25	8-80-05014	2	Stud, 1/2-13 UNF-2A
26	7-78-05009	2	Stop Pad
27	8-17-05028	1	Dump Cylinder
	0880-505	1	Seal Kit for Dump Cylinder
28	2-00-04967	4	Screw, 1/2 - 13 x 2.500 HHM
29	8-17-05030	1	Rotation Cylinder
	0880-450	1	Seal Kit for Rotation Cylinder
30	2-00-02436	1	Cotter Pin, .187 x 1.750
31	8-55-08103	1	Hopper Rotate Pin
32	8-06-01083	1	Bushing,
33	2-00-00240	4	Screw, 1/4 - 13 x 1.250 HHC
34	2-00-00426	3	Flat Washer, .500 x .218 x .062
35	2-00-00605	1	Nut, Hex MS #10 - 24 x .375 x .125
36	8-08-00743	1	Rotate Cylinder Bracket
37	7-76-00050-1	1	Spring
38	2-00-00213	2	Screw, 5/16 - 18 x .625 HHC
39	2-00-00530	2	Lock Washer, Helical Spring 5/16 Med
40	2-00-00409	2	Flat Washer, .687 x .343 x .062
41	8-50-05054	2	Rubber Pad
42	2-00-00596	2	Nut, Hex 1/2 - 13
43	8-55-08102	2	Pin (Lower)
44	8-71-00017	1	Shim
45	8-08-00742	2	Adjustable Lift Arm Bracket
46	2-95-04689	2	Washer
47	2-00-02310	2	Washer, 3/8 Lock
48	2-00-00232	2	Screw- 3/8-16 x .75 HHC



	HOPPER LIFT SYSTEM (LOW DUMP)			
	3366XP, 4366XP			21

Item	Ref. No.	Qty	Description
1	8-55-08105	1	Hopper Dump Pin
2	2-00-00518	4	Lock Washer, Helical Spring 1/4 Med
3	2-00-00221	4	Screw, 1/4 - 20 x .750 HHC
4	2-00-04432	2	Plug Button, 2.093
5	8-17-05033	2	Low Dump Cylinder
	0880-452	2	Seal Kit for Low Dump Cylinder
6	8-21-04041	2	Low Dump Lintel Edging
7	8-55-08102	2	Pin
8	2-00-00233	6	Screw, 3/8 - 16 x 1.000 HHC
9	8-18-00305	Ref	Decal, Warning Pinch Point
10	2-00-00596	6	Nut, Hex 1/2 - 13 x .750 x .437
11	2-00-00240	10	Screw, 1/2 - 13 x 1.250 HHC
12	2-00-04159	6	Flat Washer, 1/2
13	8-14-01010	2	Clevis
14	2-00-02312	10	Lock Washer, Helical Spring 1/2 Med
15	2-00-00402	2	Flat Washer, .750 x .390 x .093
16	2-00-02310	6	Lock Washer, Helical Spring 3/8 Med
17	2-00-02360	6	Nut, Hex 3/8 - 16 x .562 x .328
18	8-18-00314	Ref	Decal, Warning Service Precaution
19	8-78-05019	2	Hopper Stop
20	2-00-00598	2	Nut, Hex Jam 1/2 - 13 x .875 x .296
21	8-08-00628	2	Low Dump Hopper Stop Bracket
22	2-00-00596	4	Nut, Hex 1/2-13
23	2-00-00409	2	Flat Washer, 5/16
24	2-00-04894	2	Sleeve Bearing, 1.254 x 1.003 x 2.500
25	2-00-00530	2	Lock Washer, 5/16
26	2-00-00213	2	Screw, 5/16-18 x 5/8
27	8-08-00751	2	Low Dump Mounting Bracket
28	8-55-08104	2	Hopper Pivot Pin
29	7-21-04031	2	Edging
30	2-00-04345	2	Ty-Rap




STEERING GEAR & REAR DRIVE SYSTEM

3366XP, 4366XP


23

Item	Ref. No.	Qty	Description	Item	Ref. No.	Qty	Description
1	8-11-00022	1	Cap, Steering Wheel	36	0885-054-1	1	Hydraulic Motor
2	8-70-05287	1	Steering Column Assembly		8-70-00026	1	Key (Service)
3	2-00-00585	5	Nut, 5/16-18 Hex		8-70-00027	1	Castle Nut (Service)
4	8-17-05029	1	Cylinder		0880-237		Shaft Seal Kit (Service)
			Seal Kit:0880-449		0880-238		Motor Seal Kit (Service)
5	2-00-04895	1	Straight Fitting	37	2-00-00256	1	Set Screw, 1/4-20 x .38 HS-KCP
6	2-00-04917	1	Fitting (Red)	38	8-89-08059	1	Wheel Assy., Pneumatic
7	8-60-05023	1	Power Steering Unit		8-65-05020		Rim Assy. (Service)
			Seal Kit: 0880-654		8-85-06022		Tire Only (Service)
8	2-00-04918	2	Straight Fitting		8-70-00086		Tube (Service)
9	2-00-00432	2	Flat Washer, 3/4 ID		8-70-00067		Flap (Service)
10	2-00-00522	1	Lock Washer, 3/4 ID		8-18-00364		Decal (Service)
11	2-00-05341	1	Screw, 3/4-10 x 2.0	39	0860-536	1	Hub Assy., Rear Wheel
12	2-00-00530	5	Lock Washer, 5/16 Helical Spring		8-33-09081	1	Hub Only (Service)
13	2-00-02310	11	Lock Washer, 3/8 Helical Spring		7-80-05056-1	5	Studs (Service)
14	2-00-00232	4	Screw, 3/8-16 x 3/4 HHC	40	8-23-03065	5	Lug Nut, 1/2-20
15	7-89-08041	1	Steering Wheel	41	8-92-00043	1	Yoke, Rear Wheel
16	8-33-05109	1	Housing, Steering Unit	42	2-00-00518	4	Lock Washer, 1/4 ID
17	2-00-00208	4	Screw, 5/16-18 x 3/4 HHC	43	8-03-02036	2	Fitting, Reducer/Expander
18	8-08-00728	1	Bracket, Power Steering Unit Mount	44	2-00-04976	1	Fitting, 45° #4 SAE - #4 ORS
19	8-15-01003	1	Collar & Setscrew, 3/4	45	2-00-00594	4	Nut, 1/4-20 Hex
20	2-00-00209	4	Screw, 3/8-16 x 1.25 HHC	46	2-00-00242	4	Screw, 1/2-13 x 2.75 HHC
21	8-08-00727	1	Cylinder Pivot Weldment	47	2-00-00596	4	Nut, 1/2-13 Hex
22	2-00-02360	4	Nut, 3/8-16 Hex	48	2-00-03829	4	Lock Washer, 3/8 Int/Ext
23	2-00-05026	1	Nut, Hex, Slotted 1" x 14	49	8-08-00733	1	Bracket
24	2-00-04892	2	Fitting, 90° Elbow #4 SAE to #4 ORS	50	2-00-03266	4	Flat Washer, 3/8
26	2-00-04803	1	Cotter Pin	51	2-00-00208	2	Screw, 5/16-18 x 3/4
27	8-03-04318	1	Steering Arm	52	2-00-00409	3	Flat Washer, 5/16 ID
28	2-00-01254	6	Screw, 1/2-13 x 1.25 HHC	53	2-00-02708	1	Screw, 5/16-18 x 1.0 HHC
29	2-00-02312	8	Lock Washer, 1/2 ID	54	2-00-00776	1	Cotter Pin, .125 x 1.50
30	2-00-04621	1	Bearing Race	55	2-00-04345	3	Ty-Rap (not shown)
31	2-00-02079	1	Bearing	56	2-00-04564	2	Hose Clamp, 13/16 ID
32	8-58-05269	1	Pivot Plate	57	8-08-00578	1	Bracket
33	2-00-05358	2	Fitting, Swivel	58	8-13-07085	1	U-Bolt, 1/4-20
34	2-00-04455	1	Thrust Bearing	59	2-00-02559	1	90° Lube Fitting
35	2-00-02558	1	45° Lube Fitting	60	8-68-05097	1	Bearing Seal
				61	8-68-05098	1	Bearing Seal




	FORWARD/REVERSE ASSEMBLY (GASOLINE/LPG/DIESEL)			
	3366XP, 4366XP			25

Item	Ref. No.	Qty	Description
1	2-95-01999	4	Nut, 1/4-28 Hex Jam
2	2-00-00196	2	Carriage Bolt, 5/16-18 x 1.0
3	8-16-00045	1	Control Cable (Diesel)
4	8-55-00029	1	Pedal, Forward/Reverse
5	8-08-00723	2	Bracket, Forward/Reverse Pedal
6	2-00-03569	4	Carriage Bolt, 5/16-18 x 3/4
7	8-14-01006	1	Clevis
8	2-00-04563	1	Screw, #10-24 x .625 x .375 SH
9	2-00-01246	1	Nut, #10-24 Fiber Insert Hex
10	2-00-00530	6	Lock Washer, 5/16 Helical Spring
11	2-00-00585	6	Nut, 5/16-18 x .50 x .265 Hex
12	8-08-00898	1	Bracket, Forward/Reverse Mount
13	2-00-00409	3	Flat Washer, .687 x .343 x .062
14	2-00-00402	2	Flat Washer, .750 x .390 x .093
15	8-16-00068	1	Control Cable (Gas/LP)
16	8-17-05035	1	Lever Damper KYB
17	7-75-01130	1	Spacer
18	7-75-01209	1	Spacer
19	2-00-00644	2	Lock Nut, 5/16-18 Hex
20	2-00-00211	1	Screw, 5/16-18 x 3/4 HHC
21	2-00-00207	1	Screw, 5/16-18 x 1.25 HHC




FORWARD/REVERSE ASSEMBLY (GASOLINE & LPG ONLY)
3366XP, 4366XP
27

Item	Ref. No.	Qty	Description
1	8-60-05006-2	1	Drive Pump
2	2-00-00402	2	Flat Washer, .750 x .390 x .093
3	2-00-02310	2	Lock Washer, Helical Spring 3/8 Med
4	2-00-00209	2	Bolt, 3/8-16 x 1.25 Hex Head
5	0880-404	1	Kit, Pump Assembly
6	8-60-05022	1	Pump, Auxiliary (1.20 C.I.R.)
7	7-03-04105	1	Transmission Arm (Weldment)
8	2-00-00530	1	Lock Washer, 5/16
9	2-00-00225	1	Screw, 5/16-18 x 1.50 HHC
10	2-00-00501	24	Lock Washer, 1/4 Int.
11	7-75-01089	6	Spacer, Sandwich Mount
12	2-00-00594	6	Nut, Hex 1/4-20 x .437 x .218
13	7-58-05361	1	Plate, Hydrostat Arm
14	2-00-00219	6	Bolt, 1/4-20 x 1/2 Fin. Hex Head
15	7-75-01110	1	Spacer, Transmission Arm
16	2-00-00246	1	Screw, 1/4-20 x 2.25 HHC
17	2-00-00641	4	Nut, 1/4-20 Fiber Insert
18	8-16-00025	1	Centering Control
19	2-00-00405	1	Flat Washer, 1.062 x .531 x .093
20	2-00-00240	1	Screw, 1/2-13 x 1.25 HHC
21	2-00-04936	1	Lock Nut, 1/2-13 Elastic
22	2-00-03702	5	Washer, .625 x .281 x .063
23	2-00-01769	2	Screw, 1/4-20 x 1.75
24	7-75-01274	2	Spacer, 1/4" ID x 1/2" OD - 5/8"
25	7-25-02111	2	Rod End, 1/4 Female
26	7-66-00147	1	Rod, Centering Control Adjustment
27	2-95-01999	3	Nut, 1/4-28 Hex Jam
28	8-16-00068	1	Cable, Forward/Reverse
29	8-34-09038	1	Reflective Sleeve (1" dia. x 14")
30	2-00-04602	1	Clamp
31	2-00-01490	1	Screw, 1/4-20 x .875 Hex Head
32	2-00-04917	1	Fitting, -6 ORB to -4 ORB Reducer
33	2-00-04892	1	Fitting, 90° Elbow (O-Ring)
34	2-00-04922	2	Fitting, -8 ORS to -10 SAE 90° Elbow
35	2-00-04932	1	Fitting, Reducer
36	2-00-04926	1	Fitting, 9/16-18 x 9/16-18 Elbow
37	2-00-04974	1	Fitting, #8 ORS to #10 SAE Connector
38	2-00-04928	1	Fitting, -08 ORFS Run Tee
39	2-00-04957	1	Fitting, 8 ORS Cap
40	2-00-04920	1	Fitting, 90° Elbow
41	8-88-00065	2	Kit, Relief Valve




	FORWARD/REVERSE ASSEMBLY (DIESEL ONLY)			
	3366XP, 4366XP			29

Item	Ref. No.	Qty	Description
1	8-60-05006-2	1	Pump, Piston (1.24 C.I.R.)
2	8-60-05022	1	Pump, Auxiliary (1.20 C.I.R.)
3	0880-404	1	Kit, Pump Assembly
4	8-08-00678	1	Bracket, Hydroback
5	8-16-00025	1	Centering Control
6	2-00-00596	1	Nut, 1/2-13 Hex
7	2-00-02312	1	Lock Washer, 1/2 Helical Spring
8	2-00-00405	1	Flat Washer, 1/2
9	2-00-00240	1	Screw, 1/2-13 x 1.25 HHC
10	2-95-01999	4	Nut, 1/4-28 Hex Jam
11	7-66-00147	1	Rod, 1/4-28 x 3.0
12	7-25-02050	2	Rod End, 1/4-28
13	2-00-00225	1	Screw, 5/16-18 x 1.50 HHC
14	2-00-00530	1	Lock Washer, 5/16 Helical Spring
15	2-00-00641	2	Nut, 1/4-20 Fiber Insert Hex
16	7-03-04105	1	Transmission Arm (Weldment)
17	2-00-01246	1	Nut, #10-24 Fiber Insert Hex
18	2-00-00501	24	Lock Washer, 1/4 Int.
19	2-00-00219	6	Screw, 1/4-20 x 1/2 HHC
20	7-75-01110	1	Spacer, Transmission Arm
21	7-58-05220	1	Plate, Transmission Arm
22	2-00-00594	6	Nut, 1/4-20 Hex
23	8-16-00045	1	Cable, Forward/Reverse
24	7-75-01089	6	Isolator



	FORWARD/REVERSE ASSEMBLY (DIESEL ONLY) - CONT.			
	3366XP, 4366XP			31


Item	Ref. No.	Qty	Description
1	2-00-04926	1	ORFS 90° Elbow 9/16-18
2	2-00-04932	1	ORFS Boss Reducer, 3/4-16 x 9/16-18
3	2-00-04922	2	ORFS 90° Elbow, 1 1/16-12 to 13/16-16
4	2-00-04917	1	ORFS Boss Reducer, 9/16-18 to 7/16-20
5	2-00-04892	1	Fitting, 90° Elbow
6	2-00-04920	1	Fitting, 90° Elbow
7	8-88-00065	2	Relief Valve Kit
8	2-00-04974	1	Fitting Straight
9	2-00-04957	1	Fitting Cap
10	2-00-04928	1	Fitting Tee
11	8-60-05006-2	1	Main Pump
12	8-60-05022	1	Auxiliary Pump
13	0880-404	1	Kit, Pump Assembly



FRONT WHEEL & BRAKE ASSEMBLY			
3366XP, 4366XP			33


Item	Ref. No.	Qty	Description
1	0860-703	2	Axle, Front Wheel
2	8-75-01216	4	Spacer
3	2-00-00504	8	Lockwasher, 1/2 Int. Tooth
4	2-00-02693	8	Screw, 1/2-20 x 2.0 SHCS
5	2-00-05024	2	Thrust Washer
6	2-00-05026	2	Nut, Axle
7	2-00-02436	2	Cotter Pin
8	8-11-00030	2	Cap, Front Axle
9	8-76-00042	2	Spring
12	2-00-04621	4	Bearing Cup
13	2-00-04622	2	Bearing Cone
14	2-00-02079	2	Bearing Cone (sealed)
15	8-33-09089	2	Hub, Front Wheel
16	8-89-08054	2	Front Wheel Assy.
*	8-85-06022		Tire, Pneumatic 6 x 9
*	8-70-00067		Flap
*	8-70-00086		Tube
*	8-65-05016		Rim Assembly, 6 x 9 x 4
*	8-18-00159		Decal
17	8-80-05035	10	Stud, 1/2 -20 w/Tapered Head

*-Service Parts



BRAKE CONTROL LINKAGE			
3366XP, 4366XP			35


Item	Ref. No.	Qty	Description
1	8-70-05288	1	Shaft, Brake Pedal Pivot
2	2-00-00213	8	Screw, 5/16-18 x .625 HHC
3	8-15-01003	2	Setscrew Collar, 1.125 x .750 x .562
4	2-00-00530	10	Lock Washer, Helical Spring 5/16 Med
5	2-00-00206	1	Screw, 5/16-18 x 3/4 HHC
6	8-08-00571	2	Pivot Shaft Bracket
7	2-00-00518	1	Lock Washer, 1/4 Helical Spring
8	8-14-01006	4	Clevis
9	2-95-01999	2	Nut, 1/4-28 x .437 x .156 Hex Jam
10	8-66-00154	2	Pull Rod
11	2-00-04909	4	Yoke Pin Assembly
12	8-10-00032	1	Parking Cable
13	8-08-00756	1	Bracket, RH Brake Pedal
14	2-00-04936	1	Nut, 1/2-13 Fiber Insert Hex
15	2-00-02310	5	Lock Washer, 3/8 Helical Spring
16	2-00-00232	2	Screw, 3/8-16 x 3/4 HHC
17	2-95-04182	2	Nut, 3/8-16 Fiber Insert Hex
18	8-42-05126	1	Brake Linkage Weldment
19	2-00-00402	1	Flat Washer, .750 x .390 x .093
20	2-00-02360	4	Nut, 3/8-16 x .562 x .328 Hex
21	2-00-00234	1	Screw, 3/8-16 x 1.50 HHC
22	8-60-00140	1	Pulley
23	8-08-00436	1	Bracket, Pulley
24	8-75-01184	2	Spacer, Lever Mounting
27	2-00-00228	2	Screw, 5/16-18 x 2.50 HHC
28	7-41-05083	1	Lever, Parking Brake
29	7-55-00011	1	Pedal, Brake
30	2-00-02682	1	Screw, 1/2-13 x 2.75 HHC
31	2-00-00644	1	Nut, 5/16-18 Fiber Lock
32	8-09-01065	1	Bushing, Pulley
33	2-00-00233	2	Screw, 3/8-16 x 1.0 HHC
34	8-08-00755	1	Bracket, LH Brake Pedal
35	7-75-01126	2	Spacer, .500 x .327 x .780 (Part of #28)
36	2-00-00409	2	Flat Washer, .687 x .343 x .0625
37	2-00-01255	2	Screw, 5/16-18 x .875 HHC
38	2-00-04801	2	Flat Washer, .875 x .390 x .093
39	2-00-00209		Screw, 3/8-16 x 1.25 HHC



IMPELLER & FITTINGS			
3366XP, 4366XP			37


Item	Ref. No.	Qty	Description
1	2-00-02708	4	Screw, 5/16-18 x 1.0 HHM
2	8-56-05077	1	Fitting, Special 90° Elbow
3	2-00-01676	2	Flat Washer, 1.062 x .265 x .062
4	2-00-04885	1	Fitting, ORFS 90° Elbow, (Modified)
5	2-00-04997	1	Fitting, ORFS 1/4 NPT - #4 ORS
6	8-24-04133	1	Return Filter
7	8-75-01181	2	Spacer
8	2-00-03575	4	Carriage Bolt, 1/4-20 x .750
9	2-00-04976	1	Fitting
10	2-00-00409	10	Flat Washer, .687 x .343 x .062
11	2-00-00530	10	Lock Washer, Helical Spring 5/16 Med
12	2-00-00585	10	Nut, 5/16-18 x .50 x .265 Hex
13	8-24-04118	1	Replacement Filter Element
14	2-00-05133	4	Elbow
15	0882-041	1	Hydraulic Motor
	7-70-00020	1	Seal Kit for Hydraulic Motor 0882-041
	2-00-02227	1	Key, .125 x .750 SQ
16	2-00-02220	2	Clamp, Hose
17	8-03-04289	1	Bracket, Lower Impeller
18	8-72-00005	1	Shroud, Impeller
19	8-23-00012	1	Impeller
20	2-00-00252	4	Screw, 5/16-18 x 4.0 HHC
21*	2-00-05061	1	Insert, 1/4-20
22	2-00-00484	1	Flat Washer, .625 x .375 x .046
23	2-00-00632	1	Nut, 3/8-24 Fiber Insert Hex
24	8-29-00111	1	Gasket, Shroud
25	8-20-06028	1	Duct, Blower Throat
26	2-00-00518	9	Lock Washer, 1/4 Helical Spring
27	2-00-00594	8	Nut, 1/4-20 x .437 x .218 Hex
28	8-29-00183	1	Gasket
29*	8-08-00834	1	Bracket
30	2-00-03702	11	Flat Washer, .625 x .281 x .062
31	8-33-02271	1	Hose, Blower Exhaust
32	2-00-03454	2	Band Clamp 5 1/8-6
33	8-07-06020	1	Duct, Blower Exhaust Box
34	8-34-09009	1	Insulation, Side
35	8-34-09007	2	Insulation, Front
36	8-03-04290	1	Bracket, Upper Impeller
37	8-34-09006	1	Insulation, Blower Box (Top)
38	8-34-09005	1	Insulation, Blower Box (Bottom)
39	2-00-00196	2	Carriage Bolt, 5/16-18 x 1.0
40	2-00-01803	2	Flat Washer, 5/16
41*	2-00-00220	1	Screw, 1/4-20 x .63

*GAS & LP ONLY




		CONTROL VALVE & FITTINGS (VARIABLE DUMP)			
		3366XP, 4366XP			39

Item	Ref. No.	Qty	Description
1	2-00-04795	4	Screw, #10-24 x .750 BLTS
2	2-00-04976	2	45° Elbow, #4 SAE to #4 ORS
3	2-00-05162	1	Swivel Tee, #4 ORS
4	2-00-04892	2	ORFS 90° Elbow, #4 SAE to #4 ORS
5	2-00-04926	1	90° Elbow, #6 SAE to #4 ORS
6	2-00-04917	5	ORFS Boss Reducer, #6 SAE to #4 SAE
7	2-00-04918	2	ORFS Connector, #6 SAE to #4 ORS
8	2-00-01246	6	Nut, Hex Fiber Insert #10-24
9	8-15-01008	4	Spacer
10	8-88-00058	1	Hopper Control Valve
11	8-39-00002	2	Valve Lever Knob
12	8-41-05066	1	Control Valve Lever (L.H.)
13	8-41-05068	1	Control Valve Lever (R.H.)
14	2-00-00518	2	Lock Washer, Helical Spring 1/4 Med
15	2-00-00594	2	Nut, Hex 1/4 - 20 x .437 x .218
16	2-00-01980	2	Screw, 1/4-20 x 2.500 HHC
17	2-00-04932	2	Reducer, #8 SAE - #6 SAE
18	7-21-04031	1	Edging
19	2-00-04930	1	Fitting, Tee
20	8-41-05067	2	Linkage




		CONTROL VALVE & FITTINGS (LOW DUMP)			
		3366XP, 4366XP			41


Item	Ref. No.	Qty	Description
2	2-00-04976	3	Fitting 45° Elbow #4 SAE - #4 ORS
3	2-00-04926	2	Fitting 90° Elbow #6 SAE - #4 ORS
4	2-00-04917	3	Reducer #6 SAE
5	8-41-05066	1	Lever - L.H.
6	2-00-04930	2	Tee - #4 ORS
7	8-88-00058	1	Hopper Control Valve
8	8-39-00002	2	Knob
9	8-41-05068	1	Lever - R.H.
10	2-00-00518	2	Lock Washer - 1/4 Helical Spring
11	2-00-00594	2	Nut, Hex 1/4 - 20 x .437 x .218
12	8-41-05067	2	Linkage
13	2-00-04795	4	Screw, #10 - 24 x .750 BHS
14	2-00-04794	2	Screw, #10 - 24 x .625 BHS
15	2-00-01246	6	Nut, Hex Fiber Insert #10 - 24
16	8-15-01008	4	Spacer
17	2-00-01980	2	Screw, 1/4 - 20 x 2.500 HHC
18	2-00-04932	2	Reducer, #8 SAE - #6 SAE




Item	Ref. No.	Qty	Description
1	0885-054-1	1	Hydraulic Motor
NS	0880-238	1	Motor Seal Kit
NS	0880-237	1	Shaft Seal Kit
2	2-00-04976	1	Fitting
3	8-03-02036	2	Adapter
4	2-00-05358	2	Swivel Fitting




Item	Ref. No.	Qty	Description
1	0882-040	1	Hydraulic Motor
NS	0880-448	1	Motor Seal Kit
2	2-00-04885	2	ORFS 90° Elbow, 3/4-16 to 13/16-16
3	2-00-04895	1	ORFS Connector, 7/16-20 to 9/16-18



Item	Ref. No.	Qty	Description
1	0882-047	1	Hydraulic Motor
NS	0880-448	1	Motor Seal Kit
2	2-00-04915	2	ORFS Boss Reducer, 7/8-14 to 9/16-18
3	2-00-04926	4	ORFS 90° Elbow, 9/16-18
4	0891-008	1	Side Broom Shut-Off Valve
5	2-00-04940	2	ORFS Swivel Nut Branch Tee, #4 ORS
6	7-12-02015	1	Cartridge for Shut-Off Valve



Item	Ref. No.	Qty	Description
1	8-17-05029	2	Lift Cylinder
2	8-17-05028	1	Dump Cylinder
3	8-17-05030	1	Rotation Cylinder
4	2-00-04976	2	ORFS Connector, 7/16-20 to 9/16-18
5	2-00-04892	6	ORFS 90° Elbow, 7/16-20 to 9/16-18
6	2-00-04930	2	ORFS Union Tee, 9/16-18
NS	0880-449	1	Lift Cylinder Seal Kit
NS	0880-505	1	Dump Cylinder Seal Kit
NS	0880-450	1	Rotation Cylinder Seal Kit




Item	Ref. No.	Qty	Description
1	8-17-05033	2	Dump Cylinder
	0880-452	2	Seal Kit for Low Dump Cylinder
2	2-00-04892	4	ORFS 90° Elbow, 7/16-20 to 9/16-18
3	2-00-04930	2	ORFS Union Tee, 9/16-18

LIFT CYLINDER LOCK-OUT VALVE & FITTINGS


3366XP, 4366XP

47


Item	Ref. No.	Qty	Description
1	2-00-05162	2	Tee, Swivel #4 ORS
2	2-00-04917	1	ORFS Boss Reducer, 9/16-18 to 7/16-20
3	2-00-04918	1	ORFS Connector, 7/16-18 to 9/16-18
4	2-00-04919	1	ORFS Branch Tee, 7/16-20 x (2) 9/16-18
5	2-00-02589	4	Screw, 1/4 - 20 x 2.000 HHC
6	2-00-00641	2	Nut, Hex Fiber Insert 1/4 - 20
7	8-08-00590	1	Bracket
8	2-00-03702	4	Flat Washer, .625 x .281 x .0625
9	8-88-00044	1	Hopper Lock Valve
10	8-88-00056	1	Orifice Disc




FORM NO. 56042473



Item	Ref. No.	Qty	Description
1	8-88-00055	1	Auxiliary Manifold
	7-14-07004	1	Coil
2	2-00-04885	1	ORFS 90° Elbow, 3/4-16 / 13/16-16
3	2-00-04892	1	ORFS 90° Elbow, 7/16-20 / 9/16-18
4	2-00-04975	1	Fitting
5	2-00-04596	1	ORFS Nut, 13/16-16
6	2-00-00518	2	Lock Washer, Helical Spring 1/4 Med
7	2-00-00594	2	Nut, Hex 1/4 - 20
8	2-00-04976	1	Elbow 45° #4 SAE - ORS




Item	Ref. No.	Qty	Description
1	2-00-04596	2	Screw, 1/4-20 x 3.500 HHC
2	7-48-00019	1	Return Manifold
3	2-00-00518	2	Lock Washer, 1/4 Split
4	2-00-00594	2	Nut, Hex 1/4-20
5	2-00-04926	1	90° Elbow, O-ring
6	2-00-04976	5	45° Elbow, O-ring
7	2-00-04970	1	Fitting, Strt O-ring
8	2-00-04932	1	Fitting, Reducer SAE #8 - 6
10	2-00-05133	1	90° Elbow,
11	7-21-04031	2	Edging
12	2-00-02220	1	Hose Clamp, 13/16 to 1 1/2




	RETURN MANIFOLD ASSEMBLY (VARIABLE DUMP)			
07-6	3366XP, 4366XP			51

Item	Ref. No.	Qty	Description
1	2-00-04596	2	Screw, 1/4 - 20 x 3.50
2	7-48-00019	1	Return Manifold
3	2-00-00518	2	Lock Washer, Helical Spring 1/4 Med
4	2-00-00594	2	Nut, Hex 1/4 - 20 x .437 x .218
5	2-00-04926	3	ORFS 90° Elbow, 7/16-20 to 9/16-18
6	2-00-04976	3	45° Elbow, O-ring
7	2-00-04924	1	Swivel Tee
8	2-00-04939	1	Nut for Reducer Fitting
9	2-00-04929	2	Fitting, Reducer
10	2-00-05133	1	90° Elbow
11	2-00-04927	2	Run Tee, O-ring
12	2-00-02220	1	Clamp
13	7-21-04031	2	Edging
14	2-00-04970	2	Fitting, Straight #8 SAE - #8 ORS
15	2-00-04932	1	Fitting, Reducer #8 - #6 SAE




	HYDRAULIC RESERVOIR & FITTINGS		
	3366XP, 4366XP		53

Item	Ref. No.	Qty	Description
1	8-83-04036	1	Hydraulic Reservoir
2	8-11-00026	1	Filler Cap Assembly
3	8-24-04115	1	Strainer
4	8-48-05033	1	Sight Glass
5	8-79-00114	2	Strap
6	2-00-02220	3	Hose Clamp, .812 - 1.500
7	2-00-00518	5	Lock Washer, 1/4
8	2-00-02474	1	Pipe Plug, 1/2 NPT
9	2-00-00205	4	Screw, 1/4 - 20 x 1.000 HHC
10	2-00-00641	2	Nut, 1/4-20 Fiber Lock
11	2-00-02196	4	Carriage Bolt, 1/4 - 20 x 1.000
12	2-00-04895	1	Fitting Strt, #4 SAE - #4 ORS
13	2-00-05037	1	Adapter, 3/4 ORS x 3/4 NPT 45° Elbow
14	2-00-04572	1	Reducer, #12 Ste - 3/4 NPT
15	2-00-03585	1	Pipe Nipple, 3/4 NPT
16	2-00-03940	6	Screw, #10-24 x .500 T/C HH
17	2-00-04564	1	Hose Clamp, 13/16
18	2-00-04873	1	Clamp
19	2-00-02708	1	Screw, 5/16-18 x 1.000 HHC
20	2-00-00530	1	Lock Washer, 5/16
21	2-00-00585	2	Nut, Hex 5/16-18
22	2-00-02196	2	Carriage Bolt, 1/4-20 x 1.000




ENGINE COVER			
3366XP, 4366XP			55

Item	Ref. No.	Qty	Description
1	8-16-07338	1	Engine Cover Weldment
2	8-21-04043	1	Edging, Engine Compartment Seal
3	2-00-00233	6	Screw, 3/8 - 16 x 1.00 HHC
4	2-00-02310	6	Lock Washer, Helical Spring 3/8 Med
5	2-00-04801	6	Flat Washer, .875 x .375 x .062
6	2-00-03569	6	Carriage Bolt, 5/16-18 x .750
7	8-32-00042	1	Engine Cover Hinge
8	2-00-00409	6	Flat Washer, 5/16 x .69
9	2-00-00530	7	Lock Washer, Helical Spring 5/16
10	2-00-00585	7	Nut, Hex 5/16-18
11	8-41-00046	1	Rotary Latch
12	2-00-04794	2	Screw, #10-24 x .625 BHS
13	8-21-04042	1	Edging, Engine Compartment Seal
14	7-76-00106	1	Lever Return Spring
15	2-00-03063	1	Screw, #10-24 x .750 THM
16	7-55-08116	1	Striker Latch Pin
17	8-41-05073	1	Latch Release Lever
18	2-00-01246	3	Insert, #10 - 24 Thin Nylon
20	7-31-06061	1	Lever Cover
21	2-00-01246	1	Nut, Hex Fibre Lock #10-24
22	2-00-00594	3	Nut, Hex 1/4-20
23	2-00-00518	3	Lock Washer, Helical Spring 1/4
24	2-00-02587	3	Screw, 1/4-20 x 1.250 HHC
25	8-21-04038	1	Hand Hole Edging
26	7-78-05016	1	Engine Cover Stop
27	2-00-00641	2	Nut, Hex Fiber Lock 1/4-20
28	2-00-01769	2	Screw, 1/4-20 x 1.75 HHC



	ENGINE ACCESS DOOR			
	3366XP, 4366XP			57

Item	Ref. No.	Qty	Description
1	7-89-06545	1	Hinge
2	8-19-08071	1	Door, Lintel
3	8-41-00044	1	Latch
4	2-00-00183	7	Screw, 1/4-20 x 3/4 Round Head
5	2-00-03702	7	Washer, .625 x .281 x .063
6	2-00-00641	7	Nut, 1/4-20 Fiber Insert
FORM NO. 56042473			



Item	Ref. No.	Qty	Description
1	0777-068	1	Engine, GM 3.0 LPG
	0777-069	1	Engine, GM 3.0 GASOLINE / PETROL
2	8-08-00966	1	Bracket, Engine Mount
3	8-08-00967	1	Bracket, Engine Mount
4	8-08-00968	1	Bracket, Engine Mount
5	2-00-00402	9	Washer, 25/64 ID x 3/4 OD
6	2-00-02310	9	Lock Washer, 3/8 Helical Spring
7	2-00-00233	7	Bolt, 3/8-16 x 1.25 Fin. Hex Head
8	2-00-00209	1	Bolt, 3/8-16 x 1.25 Hex Head
9	2-00-00234	1	Screw, 3/8-16 x 1.50 HHC
10	7-35-00017	4	Isolator, Engine Mount (Red Dot)
11	2-00-05955	4	Washer
12	2-00-05067	4	Spacer, Snubbing Washer
13	2-00-02312	2	Lock Washer, 1/2"
14	2-00-02697	2	Screw, 1/2-20 x 3.0
15	2-00-00405	2	Flat Washer, 1.063 x .531 x .094
16	2-00-02617	2	Screw, 1/2-13 x 3.5 SS
17	2-00-04936	2	Nut, 1/2-13 Elastic Lock

GM 3.0 LITER - GAS & LP ENGINES (MOUNTING BRACKETS)			
08-2	3366XP, 4366XP		59

Item	Ref. No.	Qty	Description
Engine Replacement Parts			
*	56109000	1	Ecu, 06 Lp Cert 3.0l NOTE 1
*	56109001	1	Ecu, 06 Gas Cert 3.0l NOTE 2
*	56109113	1	Ecu, 07 Lp Cert 3.0l NOTE 1
*	56109114	1	Ecu, 07 Gas Cert 3.0l NOTE 2
*	0795-225	1	Harness, 3.0l Lp Engine NOTE 1
*	0795-228	1	Harness, 3.0l Gas Engine NOTE 2
*	0795-220	1	Harness: Engine - Machine Patch
*	56109002	1	Sensor, Coolant
*	56109003	1	Sensor, Crankshaft Position
*	56109004	1	Sensor, Tmap
*	56109005	1	Sensor, O2 Pre Cat
*	56109006	1	Switch, Oil Pressure
*	8-69-00013	1	Sender, Water Temp
*	8-69-00005	1	Sender, Oil Pressure
*	56109007	1	Water Pump
*	56109008	1	Oil Pump
*	56109009	1	Gasket, Cylinder Head
*	56109010	1	Gasket, Valve Cover
*	56109011	1	Gasket, Lifter Cover
*	56109012	1	Gasket, Intake Manifold
*	56109013	1	Plate, Drive, Sae 13t B-B
*	56109014	6	Bolt, Drive Plate
*	56109015	1	Distributor Assembly
*	56109016	1	Distributor Cap
*	56109017	1	Distributor Rotor
*	56109018	1	Ignition Module
*	56109019	1	Ignition Coil
*	56109020	1	Coil Wire
*	56109021	1	Spark Plug Wire Set
*	56109022	4	Spark Plug
*	56109023	1	Oil Filter
*	56109024	1	Pcv Valve
*	56109025	1	Starter
*	56109026	2	Bolt, Starter
*#	56305867	1	Alternator
*	56109028	1	Belt, Alternator
*	56109029	1	Thermostat, 180lf
*	56109030	1	Gasket, Thermostat
*	56109032	1	Gasket, Thermostat Housing
*	56109033	1	Throttle Body, Bosch 40mm
*	56109034	1	Gasket, Throttle Body
*	56109035	1	Mixer, Impco Model 100 NOTE 1
*	56109036	1	Gasket, Adapter - Mixer NOTE 1
*	56109040	1	Adapter, Mixer - Throttle Body NOTE 1
*	56109041	2	Seal, Mixer Adapter NOTE 1
*	56109042	1	O-Ring, Mixer Adapter NOTE 1
*	56109043	1	Electronic Pressure Regulator (Epr) NOTE 1
*	56109044	1	Sender, Lpg Temp - Epr NOTE 1
*	56109045	1	Fitting Kit, Epr NOTE 1
*	56109046	3	Isolator, Epr NOTE 1
*	56109047	1	Hose, Water - Epr NOTE 1
*	7-88-00110	1	Valve, Lp Safety NOTE 1
*	56109048	1	Connector, Safety Valve NOTE 1
*	56109049	1	Lock, Safety Valve Connector NOTE 1
*	56305410	1	Filter, Propane NOTE 1
*	56109050	1	Fuel Rail Assy NOTE 2
*	56109051	1	Fuel Injector NOTE 2
*#	56109185	1	Intake Manifold
*#	56109186	1	Exhaust Manifold
*#	56504459	1	Front Crankshaft Seal
**	56109084	A/R	Engine Service Kit A/R

* = Not Shown


** = Optional, Not Included

= Revised or new since last update

NOTE 1: LPG models only


NOTE 2: Gasoline / Petrol models only

FORM NO. 56042473



	GM 3.0 LITER - GAS ENGINE (FAN, AIR INTAKE & RADIATOR HOSES)			
	3366XP, 4366XP			61

Item	Ref. No.	Qty	Description
1	0777-069	1	Engine, GM 3.0 GAS
2	7-33-02712	1	Hose, Air Intake
3	56305240	1	Tube (Weldment)
4	2-00-03778	1	Plug, 1/8 NPT
5	2-00-02216	3	Clamp, Hose
6	2-00-03407	1	Clamp, Witteck #10P
7	7-75-01282	1	Spacer, Fan
8	8-23-00018	1	Fan, 15.5" Breeza
9	2-00-00530	4	Lock Washer, 5/16
10	2-00-06557	4	Screw, 5/16-24 x 2.25 Hex Head
11	8-33-02409	1	Hose, Upper Radiator
12	8-33-02410	1	Hose, Lower Radiator
13	2-00-03404	3	Clamp, Hose




	GM 3.0 LITER - LP ENGINE (FAN, AIR INTAKE & RADIATOR HOSES)				
07-1	3366XP, 4366XP				63

Item	Ref. No.	Qty	Description
1	0777-068	1	Engine, GM 3.0 LP
2	8-33-02411	1	Hose, Air Intake
3	56305240	1	Tube (Weldment)
4	2-00-03778	1	Plug, 1/8 NPT
5	2-00-02216	3	Clamp, Hose
6	2-00-03407	1	Clamp, Witteck #10P
7	2-00-05678	2	Fitting, 1/4" NPT 90° Brass Street Elbow NOTE 1
8	2-00-06569	1	Nipple, 1/4" x 2" NOTE 2
9*	7-88-00110	1	Valve, LP Safety
10	2-00-05942	1	Fitting, 1/4 NPT x 1/8 NPT x 3/8 JIC Tee
11	8-33-02415	1	Hose, LP High Pressure (102")
12	8-82-00046	1	Switch, Low Pressure
13	7-75-01282	1	Spacer, Fan
14	8-23-00018	1	Fan, 15.5" Breeza
15	2-00-00530	4	Lock Washer, 5/16
16	2-00-06557	4	Screw, 5/16-24 x 2.25 Hex Head
17	8-33-02409	1	Hose, Upper Radiator
18	8-33-02410	1	Hose, Lower Radiator
19	2-00-03404	3	Clamp, Hose

*Comes with 0777-068

NOTE 1: QTY of 1 with 2007 certified engine.


NOTE 2: Not available with 2007 certified engine.



GM 3.0 LITER - GAS & LP ENGINES (EXHAUST SYSTEM)			
3366XP, 4366XP			65

Item	Ref. No.	Qty	Description
1	0777-068	1	Engine, GM 3.0 LP
	0777-069	1	Engine, GM 3.0 GAS
2*	7-29-00344	1	Gasket, Exhaust Flange
3	8-56-04060	1	Exhaust Downpipe
4*	7-29-00345	2	Gasket, Exhaust Flange
5*	7-49-00045	1	Muffler, Catalyst
6	8-56-04061	1	Exhaust Tailpipe
7	2-00-00409	3	Flat Washer, .687 x .344 x .062
8	2-00-00530	3	Lock Washer, 5/16
9	2-00-04948	3	Screw, M8 x 1.25 x 25mm HHC
10	2-00-00402	4	Washer, 25/64 ID x 3/4 OD
11	2-00-00209	4	Bolt, 3/8-16 x 1.25 Hex Head
12	2-00-02310	4	Lock Washer, 3/8 Helical Spring
13	2-00-02360	4	Nut, 3/8-16 Hex
14	8-31-07014	1	Hanger, Muffler
15	2-00-03702	6	Washer, .625 x .281 x .063
16	2-00-01490	3	Screw, 1/4-20 x .875 Hex Head
17	2-00-00641	3	Nut, 1/4-20 Fiber Insert
18*	7-11-04081	1	O2 Sensor, GM 3.0

*Included with 0777-068 and 0777-069 engines




	GM 3.0 LITER - GAS ENGINE (FUEL SYSTEM)				
07-1	3366XP, 4366XP				67

Item	Ref. No.	Qty	Description
1	56109112	1	Fuel Tank, Gas (2007 certified models)
*	7-83-04232	1	Fuel Tank, Gas (Pre 2007 certified)
2~	7-11-04083	4	Fitting, -6 SAE x 5/16 Quick Connect
3	8-08-00974	1	Bracket, Fuel System
4	7-13-07243	4	Clamp, Fuel Pump
5~	56305062	1	Fuel Pump
7~	56305412	1	Fuel Filter
8~	7-11-04082	1	Manifold, Fuel Temperature
9~	7-11-04084	1	Fitting, -3 SAE x 5/16 Quick Connect
10	8-33-02416	4	Fuel Line, Low Permeation
11	8-33-02417	1	Fuel Line, Low Permeation
12	2-00-03702	17	Washer, .625 x .281 x .063
13	2-00-00518	9	Lock Washer, 1/4" Helical Spring
14	2-00-00219	4	Bolt, 1/4-20 x 1/2 Hex Head
15	2-00-03575	4	Carriage Bolt, 1/4-20 x 3/4
16	2-00-00198	2	Carriage Bolt, 1/4-20 x 2.0
17	2-00-00641	7	Nut, 1/4-20 Fiber Insert
18	8-26-04003	1	Float, Fuel Level
19	2-00-03829	1	Lock Washer, 3/8" Int/Ext Tooth
20	2-00-00221	6	Bolt, 1/4-20 x 3/4 Fin. Hex Head
21	8-52-00127	1	Rear Wall, Seat Compartment
22	2-00-00183	1	Screw, 1/4-20 x 3/4 round Head
23	2-00-00503	1	Lock Washer, 1/4-20
24	7-50-05144	1	Pad
25	2-00-02369	2	Nut, 3/8-16
26	2-00-00512	1	Star Washer
27	2-00-06572	1	Nut, M4 Distorted Thread
28	2-00-06573	1	Nut, M5 Distorted Thread
29	56508354	1	Cap (2007 certified models)
*	7-11-00029	1	Cap (Pre 2007 certified)

* = Not Shown


~Comes with 0777-069 Engine Assembly



GM 3.0 LITER - GAS ENGINE (FUEL SYSTEM) - CONT.			
3366XP, 4366XP			69


Item	Ref. No.	Qty	Description
1	8-08-00974	1	Bracket, Fuel System
2	7-13-07243	4	Clamp, Fuel Pump
3~	56305062	1	Fuel Pump
4~	56305412	1	Fuel Filter
5~	7-11-04082	1	Manifold, Fuel Temperature
6~	7-11-04083	2	Fitting, -6 SAE x 5/16 Quick Connect
7~	7-11-04084	1	Fitting, -3 SAE x 5/16 Quick Connect
8	8-33-02416	4	Fuel Line, Low Permeation
9	8-33-02417	1	Fuel Line, Low Permeation
10	2-00-03575	4	Carriage Bolt, 1/4-20 x 3/4
11	2-00-00198	2	Carriage Bolt, 1/4-20 x 2.0
12	2-00-03702	6	Washer, .625 x .281 x .063
13	2-00-00641	6	Nut, 1/4-20 Fiber Insert
14	2-00-06572	1	Nut, M4 Distorted Thread
15	2-00-06573	1	Nut, M5 Distorted Thread
16~	56109052	1	Fitting, Fuel Pump

~Comes with 0777-069 Engine Assy.



	RADIATOR ASSEMBLY - GM 3.0 LITER ENGINE (GASOLINE & LPG)			
	3366XP, 4366XP			71

Item	Ref. No.	Qty	Description
1	7-62-01008	1	Radiator
2	8-72-00021	1	Shroud, Radiator
3	8-72-00022	1	Shroud, Oil Cooler
4	2-00-05261	6	Insert, 1/4-20 Threaded
5	8-62-01018	1	Oil Cooler
6	7-29-00192	2	Gasket, Oil Cooler
7	8-13-07088	2	Clip
8	2-00-00518	8	Lock Washer, 1/4" Helical Spring
9	2-00-00246	2	Bolt, 1/4-20 x 2.25 Hex Head
10	8-08-00946	1	Bracket, Radiator Mounting
11	8-50-05053	2	Isolator, Radiator Mount
12	2-00-03702	18	Washer, .625 x .281 x .063
13	2-00-00501	4	Washer, .25 ID x .44 OD x .046
14	2-00-00594	4	Nut, 1/4-20 Hex
15	2-00-00221	10	Screw, 1/4-20 x 3/4 HHC
16	2-00-05956	1	Plug, Radiator Outlet
17	2-00-02216	1	Clamp, Hose
18	7-07-02002	1	Overflow Bottle Assy. (1 liter)
19	2-00-04602	3	Clamp
20	2-00-05985	1	Cap, 3/8 ID x 1 Inside Length (Rubber)
21	2-00-05363	2	Clamp, Hose
22	7-33-02642	1	Hose, 1/4" ID x 18" long (Black)
23	7-33-02643	1	Hose, 1/4" ID x 36" long (Black)
24	2-00-00641	4	Nut, 1/4-20 Fiber Insert
25	2-00-04970	2	Fitting, Str. -8 ORS x -8 SAE




LP TANK SYSTEM			
3366XP, 4366XP			73

Item	Ref. No.	Qty	Description
1	2-00-00518	12	Lock Washer, Helical Spring 1/4 Med
2	2-00-00219	9	Screw, 1/4-20 x .500 HHC
3	8-65-00041	1	Rear Retainer
4	8-08-00619	1	Bracket, Tapped
5	8-83-04016	1	LP Tank
6	8-78-05018	1	Bumper, LP Tank Stop
7	2-00-02312	5	Lock Washer, Helical Spring 1/2 Med
8~	REF		Light, Check Engine (Gas/LP)
	2-00-04757	1	Hole Plug (Diesel)
9	8-81-00144	2	Tank Support
10*		1	Fitting, 1/4 NPT x 3/8 SAE Str.
11*		1	Fitting, Bulk Head Plus Hardware
12	8-52-00122	1	Wall, Seat Compartment
13	8-65-00042	1	Retainer, LP Tank
14	2-00-00409	2	Flat Washer, 5/16
15	2-00-04867	2	Screw, 5/16-18 x 1.000 Thumb
16*		1	Fitting (comes with LP tank)
17*		1	Coupling
18*		2	Fitting, 1/4 NPT x 3/8 SAE 90 elbow
19*		1	Hose, Tank to Relief Valve
20*		1	Fitting, 1/4 NPT x 1/4 FM 45 Elbow
21*		1	Relief Valve
22*		1	Plastic Cap
23	2-00-00239	5	Screw, 1/2-13 x 1.000 HHC
24	2-00-02310	1	Lock Washer, 3/8
25	8-08-07052	1	Bumper, LP Tank Stop
26	8-41-00040	1	Latch, Bumper
27	2-00-00407	7	Flat Washer, .562 x .265 x .062
28	2-00-00221	2	Screw, 1/4-20 x .750 HHC
29	8-08-00620	1	Bracket, Locating Pin
30	8-33-02262	Ref	Hose, 88", Engine to Relief Valve (FORD)
31	8-13-07091	1	Clamp, LP Hose
32	2-00-04564	1	Clamp, Cable
33	8-09-01077	1	Grommet
34	2-00-00205	1	Screw, 1/4-20 x 1.00 HHC
35	2-00-00594	1	Nut, Hex 1/4-20 x .437 x .218
36	7-11-04035	1	Kit, Low LP Indicator Light
37	2-00-00596	2	Nut, 1/2-13


*All Parts without a number are contained in LP Kit Number 8-11-04014

~Comes with Engine Assembly



	AIR CLEANER ASSEMBLY (GASOLINE/LPG/DIESEL)			
07-1	3366XP, 4366XP			75

Item	Ref. No.	Qty	Description
1	8-24-04093	2	Clamp, Air Cleaner
2	8-24-04100	1	Air Cleaner Assembly
	8-24-04106		Air Cleaner Element (exterior)
	8-24-04111		Air Cleaner Element (interior)
3	8-24-04092	1	Filter, Dust Bowl
4	2-00-03641	1	Elbow, 1/8 NPT
5			Intentionally Omitted
6	7-24-04087	1	Filter Service Indicator 20" WC (Diesel)
	56478461	1	Indicator, Service (Gasoline / Petrol & LPG)
7	8-33-02369	1	Hose, Intake (Diesel)
8	8-33-02412	1	Hose, Intake (LPG)
9	8-33-02413	1	Hose, Intake (Gasoline / Petrol)
10	7-21-04022	1	Edging
11	2-00-02217	2	Clamp, Hose
12	8-58-05263	1	Plate, Filter Assy.
13	2-00-02196	2	Carriage Bolt, 1/4-20 x 1.00
14	2-00-03027	2	Screw, 1/4-20 x .63 Cap
15	2-00-00518	4	Lock Washer, 1/4 Helical Spring
16	2-00-00594	4	Nut, 1/4-20 Hex




		MITSUBISHI S4Q2 - DIESEL ENGINE (FAN, BRACKETS, THROTTLE)			
08-2	3366XP, 4366XP				77

Item	Ref. No.	Qty	Description	Item	Ref. No.	Qty	Description
1	0777-052	1	Engine Assy., Mitsubishi S4Q2 Diesel	*	0775-287	1	Alternator
2	7-75-01248	1	Spacer, S4Q2 Engine Fan	*	7-23-00022	1	Fan, S4Q2 Engine
3	7-23-00022	1	Fan, S4Q2 Engine	*	2-00-05968	1	Belt, Alternator/Fan
4	7-16-05045	1	Coupling, Engine	*	7-60-05048	1	Water Pump
5	7-33-05144	1	Casting, Pump Plate	*	7-29-00339	1	Gasket, Water Pump
6	2-00-05963	8	Screw, M8 x 1.25 x 15mm 8.8 Blox	*	7-24-04097	1	Oil Filter
7	2-00-05042	18	Lock Washer, M10 Helical Spring	*	7-75-03005	4	Glow Plug
8	2-00-05961	12	Screw, M10 x 1.25 x 30mm HHC	*	7-64-00041	1	Relay, Glow Plug (installed on wire harness)
9	7-08-01192	1	Bracket, Engine Mount	*	7-64-00040	1	Relay, Murphy (installed on wire harness)
10	7-08-01193	1	Bracket, Engine Mount	*	0769-029	1	Injector
11	7-08-01194	1	Bracket, Engine Mount	*	7-29-00338	1	Gasket, Cylinder Head
12	7-08-01195	1	Bracket, Engine Mount	*	7-56-04071	1	Pipe, Cylinder #1
13	7-35-00017	4	Isolator, Engine Mount (Red Dot)	*	7-56-04072	1	Pipe, Cylinder #2
14	2-00-05955	4	Washer, 1.25 ID x 2.00 OD x .25	*	7-56-04073	1	Pipe, Cylinder #3
15	2-00-05067	4	Spacer, Snubbing Washer	*	7-56-04074	1	Pipe, Cylinder #4
16	2-00-02617	4	Screw, 1/2-13 x 3.5 LG SS	*	7-56-04079	1	Pipe, Fuel Leak-Off
17	2-00-04936	4	Nut, 1/2-13 Elastic Lock	*	7-29-00312	1	Gasket, Thermostat
18	2-00-05043	8	Washer, 25/64 ID x 3/4 OD Plain	*	7-84-08016	1	Thermostat
19	2-00-05957	8	Screw, M12 x 1.75 x 25mm HHC	*	0775-285	1	Starter
20	2-00-05958	6	Screw, M10 x 1.25 x 20mm HHC	*#	7-24-04088	1	Element, Water Separator
21	8-08-00938	1	Bracket, Throttle	*#	7-24-04089	1	Element, Fuel Filter
22	8-13-07094	1	Clamp, Conduit	*	8-24-04100	1	Air Cleaner Assembly
23	7-10-00024	1	Cable, Throttle (80")	*	8-24-04106	1	Air Filter Element (exterior)
24	8-25-02036	1	Connector, Ball Joint	*	8-24-04111	1	Air Filter Element (interior)
25	8-03-04321	1	Arm, Throttle	*	7-82-00052	1	Switch, Water Temperature
26	8-90-07328	1	Wire, Ground to Frame	*	7-82-00055	1	Switch, Oil Pressure (for Murphy Shutdown)
27	2-00-00232	1	Bolt, 3/8-16 Fin. Hex Head	*#	56504421	1	Shutdown Solenoid & Linkage
28	2-00-03829	2	Lock Washer, 3/8 Int./Ext. Tooth	*#	56504455	1	Piston Ring Set
29	2-00-02360	1	Nut, 3/8-16 Hex	*#	56504456	1	Con Rod Bushing
30	2-00-04794	2	Screw, #10-24 x .63 BHS				
31	2-00-00426	2	Flat Washer, .500 x .219 x .063				
32	2-00-01246	2	Nut, #10-24 Elastic Stop				
33	2-00-05528	2	Screw, M6 x1.0 x 12mm HHC				
34	2-00-00626	1	Nut, 10-32				
35	2-00-00633	1	Nut, 1/4-28 Fiber Insert				
36	2-00-05981	4	Screw, M8 x 1.25 x 55mm HHC				


* = Not Shown

= Revised or new since last update




	 MITSUBISHI S4Q2 - DIESEL ENGINE (EXHAUST SYSTEM) 			
07-1	 3366XP, 4366XP 			79

Item	Ref. No.	Qty	Description
1	7-87-02933	1	Tube, Exhaust
2	7-49-00031	1	Muffler
3	2-00-04040	2	Clamp, 1/4" Muffler
4	7-31-07033	1	Hanger, Muffler




	 MITSUBISHI S4Q2 - DIESEL ENGINE (FUEL SYSTEM) 			
	 3366XP, 4366XP 			 81

Item	Ref. No.	Qty	Description
1	8-08-00939	1	Bracket, Murphy
2	8-08-00940	1	Bracket, Fuel Filter
3	7-24-04078	1	Filter, Diesel Fuel
4	8-60-05028	1	Pump, Fuel
5	2-00-05261	2	Insert, 1/4-20 Threaded
6	2-00-00518	2	Lock Washer, 1/4" Helical Spring
7	2-00-00221	2	Bolt, 1/4-20 x .75 Fin. Hex Head
8	2-00-04388	2	Clamp, Hose
9	2-00-05041	2	Lock Washer, M8 Helical Spring
10	2-00-05963	2	Screw, M8 x 1.25 x 15mm 8.8 Blox
11	2-00-04801	2	Flat Washer, 1.00 x .39 x .06
12	2-00-04363	2	Screw, M8 x 1.25 x 20mm
13	2-00-00209	2	Bolt, 3/8-16 x 1.25 Hex Head
14	2-95-04182	2	Nut, 3/8-16 Hex Stop
15	8-08-00936	1	Bracket, Murphy
16	7-64-00040	1	Relay, Glow Plug
17	7-64-00041	1	Relay, Murphy
18	2-00-00512	2	Star Washer
19	2-00-00052	2	Screw, #10-24 x .38 RHMS
20	2-00-00049	2	Screw, 10-24 x .50 RHM
21	2-00-01246	2	Nut, #10-24 Elastic Stop
22	8-33-02338	1	Hose, Fuel
23	8-33-02154	1	Hose, Fuel







	RADIATOR ASSEMBLY (DIESEL)			
	3366XP, 4366XP			83

Item	Ref. No.	Qty	Description
1	7-62-01008	1	Radiator
2	8-08-00946	1	Bracket, Radiator Mounting
3	8-50-05053	2	Isolator, Radiator Mount
4	8-72-00020	1	Shroud, Radiator
5	8-72-00019	1	Shroud, Oil Cooler
6	2-00-03702	4	Washer, .625 x .281 x .063
7	2-00-00501	4	Washer, .25 ID x .44 OD x .046
8	2-00-00594	4	Nut, 1/4-20 Hex
9	8-62-01018	1	Oil Cooler
10	7-29-00192	2	Gasket, Oil Cooler
11	8-13-07088	2	Clip
12	2-00-00518	4	Lock Washer, 1/4" Helical Spring
13	2-00-00246	2	Bolt, 1/4-20 x 2.25 Hex Head
14	2-00-00220	2	Screw, 1/4-20 x .625 HHC
15	2-00-05956	1	Plug, Radiator Outlet
16	8-33-02367	1	Hose, Upper Radiator
17	8-33-02615	1	Hose, Lower Radiator
18	2-00-03404	4	Clamp
19	2-00-05261	4	Insert, 1/4-20 Threaded
20	7-07-02002	1	Overflow Bottle Assy. (1 liter)
21	2-00-00219	4	Bolt, 1/4-20 Fin. Hex Head
22	2-00-05985	1	Cap, 3/8 ID x 1 Inside Length (Rubber)
23	2-00-05363	3	Clamp, Hose
24	7-33-02724	1	Hose, 1/4" ID x 28" long (Clear)
25	7-33-02643	1	Hose, 1/4" ID x 36" long (Black)
26	2-00-04970	2	Fitting, Str. -8 ORS x -8 SAE
27	2-00-02216	1	Clamp, Hose




	FUEL TANK (DIESEL)			
	3366XP, 4366XP			85

Item	Ref. No.	Qty	Description
1	8-83-04029	1	Fuel Tank
2	8-33-02338	REF	Hose, Fuel
3	2-00-02369	2	Nut, Hex Jam 3/8 - 16 x .562 x .218
4	7-50-05144	1	Pad
5	2-00-04618	1	Barb Fitting
6	2-00-00518	5	Lock Washer, Helical Spring 1/4 Med
7	2-00-04602	1	Clamp, Fuel Line
8	7-11-00029	1	Fuel Tank Cap
9	8-56-05021	1	Fitting
10	2-00-03829	1	Star Washer
11	2-00-00512	1	Star Washer
12	8-52-00127	1	Rear Wall, Seat Compartment
13	2-00-00221	5	Screw, 1/4-20 x 3/4 HHC
14	2-00-00205	1	Screw, 1/4-20 x 1.0 HHC
16	8-26-04003	1	Float, Fuel Tank Sender
17	2-00-00503	2	Lock Washer, 1/4 Int/Ext
18	2-00-03702	7	Flat Washer, 1/4
19	2-00-00183	1	Screw, 1/4-20 x 3/4 THM
20	2-00-00641	2	Lock Nut, 1/4-20



CE KIT (3366XP only)				
07-1	3366XP, 4366XP			87

Item	Ref. No.	Qty	Description
	0880-689	1	CE Kit (3366XP only)
1	2-00-00624	2	Nut, Hex 6-32
2	7-82-00009	1	Switch
3	2-00-05060	2	Screw, 6-32 x 1.25
4	2-00-01499	2	Lockwasher, #6
5	2-00-00455	2	Washer-Flat #6
6	2-00-04808	2	Fork Terminal-L
7	8-32-09009	1	Backup Alarm
8	2-00-04282	1	Ring Terminal
9	2-00-04578	1	Terminal-Bullet
10	2-00-00213	2	Screw 5/16-18 x .62
11	2-00-02303	2	Washer-Lock 5/16
12	2-00-00409	2	Washer-Flat 11/32
13	2-00-00585	2	Nut, 5/16-18
14	8-64-00008	1	Circuit Breaker 15 Amp
15	8-11-00044	1	Boot
16	8-11-00015	1	Spade Terminal
17	7-35-00013	1	Insulation
18	8-79-00030	1	Static Strap
19	7-41-05099	2	Lever-Parking Brake
20	2-00-02310	1	LK Wash Helical Spr ZN
21	2-00-02360	1	Nut, Hex Fin .38
22	2-00-03829	1	LK Wash Int/E
23	2-00-00402	2	Wshr-FL .750 x .391 x .093 STL ZN
24	2-00-00233	1	Screw-HHC .375-16 x 1.00 GR ZN




DECALS			
3366XP, 4366XP			89

Item	Ref. No.	Qty	Description
1	8-18-00518	1	Hopper Controls
2	8-18-00512	1	Instrument Panel
3	8-18-00519	1	Main Broom & Throttle (Diesel only)
	8-18-00555	1	Main Broom & Throttle (Gas/LPonly)
4*	REF	1	Hydraulic Fluid Only
5	8-18-00490	1	Bi-directional Pedal (horizontal)
6	8-18-00487	1	Blank Squares - Option Cover
7<	REF	1	Gasoline Only
	REF	1	Diesel Only
8*<	REF	1	Do Not Use With Flammables
9*<	REF	1	Exhaust Warning
10<	REF	1	Fire Hazard
11<	REF	1	Moving Belts - Stay Clear
12<	REF	1	Moving Fan Blade-Stay Clear
13*<	REF	1	Patent/Patent Pending
14<	REF	1	Surface Hot - Stay Clear
15<	REF	1	Turn Off - Lock Wheel
16*<	REF	2	Put Hopper in Forward Dump Position
17*<	REF	3	Split rim (Pneumatic Tire)
18<	REF	4	Pinch Point - Stay Clear
19	8-18-00569	1	4366XP
	8-18-00556	1	3366XP (Export Only)
20	8-18-00549	1	American-Lincoln Technology (Export only)
21	8-18-00525	1	American-Lincoln (Medium)
	8-18-00528	1	Alto (Export only)
22	8-18-00524	2	American-Lincoln (Small)
	8-18-00548	1	American-Lincoln Technology (Export only)
23	REF	1	Serial Number Plate
24	7-50-05136	1	Non-Skid, Frame Edge
25	8-50-05055	1	Non-Skid, Forward/Reverse Pedal
26	8-50-05050	1	Non-Skid, Brake Pedal
27	8-50-05052	1	Non-Skid, Drive Compartment Floor
28	2-00-04115	2	Pop Rivet

<English Text and 4366XP No-text warning decals contained in kit 0760-871

*ALL WARNING/SAFETY DECALS WITH TEXT SOLD IN A KIT BY LANGUAGE:

DANISH	0760-850	ITALIAN	0760-851
DUTCH	0760-849	FRENCH	0760-847
NORWEGIAN	0760-852	SPANISH	0760-846
SWEDISH	0760-853	PORTUGUESE	0760-854
GERMAN	0760-848		




INSTRUMENT PANEL			
3366XP, 4366XP			91

Item	Ref. No.	Qty	Description
1	0895-132	1	Instrument Panel Harness
2	7-11-04035	1	Kit, Low LP Indicator Light (LP only)
3	8-48-05028	1	Water Temperature Gauge
4	8-48-05023	1	Hour Meter Gauge
5	8-48-00016	1	Volt Meter Gauge
6	8-48-05027	1	Oil Pressure Gauge
7	7-82-00026	1	Key Switch (Key only: 2-60-02272)
8	2-00-00512	8	Lock Washer #10 Int
9	2-00-04694	4	Nut, Hex MS #10 - 32 x .375 x .125
10	8-82-00024	1	Horn Push Button
11	8-82-00062	1	Switch - SPST (Momentary) ON-OFF
12	8-82-00059	1	Switch - SPST ON-OFF
13	8-64-00013	1	Circuit Breaker (25 Amp)
14	8-11-00044	5	Boot (Circuit Breaker)
15	2-00-04757	2	Plug Button, .375 Circuit Breaker
16	2-00-01499	2	Lock Washer, #6
17	2-00-00624	2	Nut, Hex #6-32
18	8-64-00012	1	Shaker Motor Relay
19	2-00-03063	3	Screw, #10 - 24 x .750 THM
20	2-00-00466	4	Flat Washer, .625 x .203 x .031
21	2-00-00605	12	Nut, Hex MS #10 - 24 x .375 x .125
22	2-00-00519	8	Lock Washer, Helical Spring #10 Med
23	8-08-00748	1	Relay Bracket
24	2-00-04897	2	Screw, #10 - 24 x 1.250 THM
27	8-48-05032	1	Fuel Gauge (Gas & Diesel only)
28	8-90-07357	2	Wire, W.T. Gauge to F.G. (Gas & Diesel only)
29	2-00-04942	2	Plug Button, .530 (Light Switch)
30	8-82-00062	1	Switch -SPST (Momentary)ON-OFF (Diesel)
31	2-00-04937	1	Tie Cable
32	8-64-05009	1	Relay, Broom and Fan
33	2-00-03061	9	Screw, #10 - 24 x .500 THM
35	8-64-00008	4	Circuit Breaker (15 AMP)
36	8-64-05011	1	Relay (20 Sec. Time Delay) (Option)
38	2-00-00455	2	Flat Washer, #6
39	2-00-00067	2	Screw, #6-32 x 1.00 RHM
43	8-90-07361	1	Wire - TD-1 #6 to #7 to M2 #86 to M4 #68
44	8-90-07385	1	Wire - Jumper

HYDRAULIC HOSE SYSTEM (VARIABLE DUMP)

92


3366XP, 4366XP



	HYDRAULIC HOSE SYSTEM (VARIABLE DUMP)			
	3366XP, 4366XP			93

Item	Ref. No.	Qty	Description
1*	8-33-02184	1	Hose, #4 x 50.5" -0-0-ORS-1WB
2*	7-33-02225	3	Hose, #4 x 38.0" -0-90-ORS-1WB
3*	8-33-02198	1	Hose, #4 x 107.0" -0-90-ORS-1WB
4*	8-33-02185	3	Hose, #4 x 56.0" -0-0-ORS-1WB
5*	7-33-02193	1	Hose, #4 x 49.0" -0-90-ORS-1WB
6*	8-33-02217	1	Hose, #4 x 32.0" -0-0-ORS-1WB
7*	8-33-02174	1	Hose, #4 x 16.5" -0-90-ORS-1WB
8	8-33-02178	REF	Hose, #4 x 15.0" -0-0-ORS-1WB
9*	8-33-02204	1	Hose, #4 x 76.0" -0-90-ORS-1WB
10*	8-33-02179	1	Hose, #4 x 46.0" -0-0-ORS-1WB
11	8-33-02329	1	Hose, #4 x 30.0" -0-0-90-ORS-1WB (Diesel Only)

*Part of Hose Kit 0860-753




	HYDRAULIC HOSE SYSTEM (VARIABLE & LOW DUMP)			
	3366XP, 4366XP			95

Item	Ref. No.	Qty	Description
1*<	8-33-02267	2	Hose, #8 x 62.0" -0-0-ORS-2WB
2*<	7-33-02189	1	Hose, #4 x 26.0" -0-90-ORS-1WB
3*	8-33-02215	1	Hose, #12 x 36.0" -0-0-ORS-1WB
4*<	8-33-02265	2	Hose, #8 x 23.0" -0-45-ORS-2WB
5	8-33-02273	1	Hose, 1 x 15.0" Return
6*<	8-33-02418	1	Hose, #8 x 52.0" -0-90-ORS-1WB
7	7-33-02317	1	Hose, 1 x 15.0" Return
8*<	8-33-02553	1	Hose, #8 x 90.0" -0-0-ORS-2WB
9*<	7-33-02190	3	Hose #4 x 67.0" -0-90-ORS-1WB
10*<	7-33-02200	1	Hose, #4 x 56.0" -0-90-ORS-1WB
11*<	8-33-02278	1	Hose, #4 x 130.0" -0-0-ORS-1WB
12*<	8-33-02195	1	Hose, #8 x 69.5" -0-0-ORS-2WB
13*<	7-33-02193	1	Hose, #4 x 49.0" -0-90-ORS-1WB
14*<	7-33-02206	1	Hose, #8 x 14.25" -0-90-ORS-1WB
15*<	8-33-02277	1	Hose, #4 x 110.0" -0-0-ORS-1WB
16<	8-33-02191	1	Hose, #8 x 56.5" -0-0-ORS-2 WB
17*<	8-33-02178	1	Hose, #4 x 15.0" -0-0-ORS-1WB
18<	8-33-02194	1	Hose, #12 x 32.0" -0-0-ORS-1WB
19*<	8-33-02217	1	Hose, #4 x 32.0" -0-0-ORS-1WB
20*	8-33-02196	1	Hose, #8 x 75.5" -0-0-ORS-2WB


*PART OF HOSE KIT 0860-755 (GAS/LP MODELS)

<PART OF HOSE KIT 0860-756 (DIESEL MODELS)



	HYDRAULIC HOSE SYSTEM (LOW DUMP)			
	3366XP, 4366XP			97

Item	Ref. No.	Qty	Description
1	8-33-02185	2	Hose, #4 x 56.0" -0-0-ORS-1WB
2	8-33-02177	2	Hose, #4 x 73.0" -0-0-ORS-1WB
3	8-33-02217	1	Hose, #4 x 32.0" -0-0-ORS-1WB
4	8-33-02184	1	Hose, #4 x 50.5" -0-0-ORS-1WB
5	8-33-02178	REF	Hose, #4 x 15.0" -0-0-ORS-1WB
6	8-33-02198	REF	Hose #4 x 107.0" -0-90-ORS-1WB
7	7-33-02206	REF	Hose, #8 x 14.25" -0-90-ORS-1WB
8	8-33-02418	REF	Hose, #8 x 52.0" -0-90-ORS-1WB
9	7-33-02225	1	Hose, #4 x 38.0" -0-0-ORS-1WB
10	7-33-02186	2	Hose, #4 x 30.0" -0-ORS-1WB




	HARNESS ROUTING - GAS/LP/DIESEL			
	3366XP, 4366XP			99

Item	Ref. No.	Qty	Description
1	0895-131	1	Machine Harness
2	8-09-01081	2	Bushing, Snap
3	7-13-07096	17	Clamp, Adjustable
4	2-00-04345	5	Ty-Rap
5	2-00-00594	1	Nut, 1/4-20 Hex
6	2-00-00641	1	Nut, 1/4-20 Fiber Lock
7	2-00-00503	2	Washer, 1/4 Int. - Ext.
8	2-00-00205	1	Screw, 1/4-20 x 1.0 HHC
9	2-00-04937	1	Cable Tie
10	2-00-03063	1	Screw, 10-24 x 3/4 THM
11	2-00-00585	1	Nut, Hex 5/16-18 x .500 x .265
12	2-00-00519	1	Lock Washer, #10 Helical Spring
13	2-00-00605	1	Nut, #10-24 x .375 x .125 Hex
14	2-00-01246	1	Nut, #10-24 Fiber Lock
15	8-32-09013	1	Horn
16	2-00-00208	1	Screw, 5/16-18 x 3/4 HHC
17	2-00-02303	2	Lock Washer, 5/16

WIRING DIAGRAM

3366XP, 4366XP

100



American-Lincoln®

14600 21st Avenue North
Plymouth, MN 55447-3408
www.americanlincoln.com
Phone: 800-331-7692
Fax: 877-877-2586
©2008 American-Lincoln