



Electronic Service Manuals

This electronic document is provided as a service to our customers. We do not create the contents of the information contained in this document. Should you have detailed questions pertaining to the information contained in this document, you may contact Michco, or the manufacturer which provided the original information in this electronic deliverable. Michco's only part in this electronic deliverable was the electronic assembly process. By providing this manual on line we are not guaranteeing parts availability.

You may contact Michco through the following methods:

Phone (517) 484-9312 or (800) 331-3339

2011 N. High St. -- Lansing, Michigan -- 48906

Fax: (517) 484-9836

Email: CustServe@Michco.com

Web site: www.Michco.Com

Parts Web site: www.FloorMachineParts.Com

Order Parts on Line at:

www.FloorMachineParts.Com

Directly to Parts & Service:

By Email: **Shop@Michco.com**

By Fax: (517) 702-2041

By Voice: Use numbers above.

Serving the Cleaning Industry Since 1922

Notice: All copyrighted material remains property of original owners, all trademarks are property of respective owners. Manuals are subject to Manufacturer's reproduction limitations. Originals or reproductions were provided by manufacturers through a request. We make no warranty as to the correctness of information provided in this document and you assume all risk. By placing these manuals on line we are not declaring our corporation to be an manufacturer authorized dealer or provider, please check our web site for authorized manufacturers we represent.

REPAIR PARTS

MODEL NO. HS-7830A

- SWEEPER UNIT ASSEMBLY -




Figure 13

PARTS LIST

Ref. No.	Part No.	Qty. Per Unit	Description of Part	Ref. No.	Part No.	Qty. Per Unit	Description of Part
1	75-160	1	Hood 68-13-C	19	68-60 -A-	2	Ball Bearing
2	351-116-18	2	Wing Nut 1/4-20	20	55-161 -A-	2	Special Washers
3	60-22-B	2	Hood Clamp	21	75-89 -A-	4	Retainer
4	945-516	4	Plain Washer 5/16	22	362-416	8	Hexagon Lock Nut 1/4-20
5	68-10-C	1	Hood Extension 68-49-B	23	69-04 -A-	8	Brush Clamp
6	70-416-12	2	Carriage Bolt 1/4-20 x 3/4	24	74-16 -A-	4	Brush Stud
7	560-C-516-10	4	Set Screw 5/16-18 x 5/8	25	74-13 -C-	8	Brush Bracket
8	68-04	1	Left Hand Side Plate 71-05-LD	26	77-137 -B-	1	Reel Shaft
9	73-71-A	1	Wing Nut 5/16	27	1200-14.5	8	Brush Strip
10	50-33 -A	2	Special Washer	28	62-04 -A-	1	Bottom Tie Rod
11	74-80 -A *	4	Pawl	29	68-03	1	Right Hand Side Plate 71-04-RD
11A	76-37 -A *	4	Pawl Spring	30	78-131 -A-	1	Adjusting Tube
12	74-79 -B *	1	Left Hand Pinion	31	78-133 -A-	1	Adjusting Bolt
13	74-78 -RB *	1	Right Hand Pinion	32	945-616	1	Plain Washer 3/8
14	49-377 -C-	2	Wheel	33	78-132 -A-	2	Hood Control Rod
15	46-81 -A-	4	Special Washer	34	946-816-16	2	Washer-Fiber
16	380-432-16	2	Cotter Pin 1/8 x 1	35	71-37 -A-	2	Washer-Special
17	78-124 -C-	2	Tire				
18	946-1216-24	4	Fiber Washer				

REPAIR PARTS

MODEL NO. HS-7830A

- FRAME ASSEMBLY -




Figure 14

PARTS LIST

Ref. No.	Part No.	Qty. Per Unit	Description of Part	Ref. No.	Part No.	Qty. Per Unit	Description of Part
1	74-75	1	Hitch Pin 81-14-A	25	76-81-B	2	Caster Plate
2	365-416	8	Hexagon Lock Nut 1/4-20	26	76-307-B	1	Frame Support
3	65-416-24	4	Hexagon Cap Screw 1/4-20 x 1-1/2	27	76-306-LC	1	Lower Frame Left Hand
4	76-309-LC	1	Upper Frame Left Hand	29	76-255-A	1	Basket Stop
5	335-516	2	Hexagon Nut 5/16-18	30	945-416	1	Plain Washer 1/4
6	935-516	2	Spring Lock Washer 5/16	31	76-271-A	1	Compression Spring
7	76-139-A	2	Washer	32	75-89-A	1	Retainer
8	59-77-A	4	Tube Clamp	33	65-416-20	4	Hexagon Cap Screw 1/4-20 x 1-1/4
9	69-516-24	2	Contour Head Bolt 5/16-18 x 1-1/2	36	65-516-32	2	Hexagon Cap Screw 5/16-18 x 2
10	54-227-A	2	Spacer	37	365-516	2	Hexagon Lock Nut 5/16-18
11	945-516	4	Plain Washer 5/16	40	69-416-28	4	Contour Head Bolt 1/4-20 x 1-3/4
12	69-416-20	4	Contour Head Bolt 1/4-20 x 1-1/4	41	380-432-16	2	Cotter Pin 1/8 x 1
13	76-240-A	2	Pivot Bracket	42	69-75-A	1	Adjusting Bolt
14	935-416	8	Spring Lock Washer 1/4	43	73-71-A	1	Wing Nut 5/16-18
15	335-416	8	Hexagon Nut 1/4-20	44	53-08	1	Spacer 80-213-A
16	76-308-RC	1	Upper Frame Right Hand	45	60-21-A	2	Brush Adjusting Bracket
20	76-305-RC	1	Lower Frame Right Hand	47	76-246-C	1	Yoke 83-23-L YOKE *
21	76-143	2	Fork Assembly R/W 76-136-B	48	76-233-C	2	Tee Clamp
23	76-58-A	2	Roller 78-136-A	49	76-247-A	2	Clevis Lug
24	76-202-A	2	Axle	50	76-243-A	1	Tongue 89-103-A

- BASKET ASSEMBLY -




Figure 15

PARTS LIST

Ref. No.	Part No.	Qty. Per Unit	Description of Part	Ref. No.	Part No.	Qty. Per Unit	Description of Part
1	76-319-B	1	Rear Basket Frame	12	69-62	2	Pivot Bracket 79-112-B
2	76-252-A	1	Rope Clip	13	76-246	1	Lower Basket Frame 83-81-C
3	60-09-A	1	Rope	14	76-295-B	2	Front Basket Frame
4	76-328-B	1	Basket Spring	15	935-516	2	Spring Lock Washer 5/16
5	76-329	1	Basket Sides and Bottom SA-1178-C	16	76-269-A	2	Lag Bolt 5/16 x 1-1/2
6	69-416-20	4	Contour Head Bolt 1/4-20 x 1-1/4	17	76-270-A	2	Insert
7	935-416	4	Spring Lock Washer 1/4	18	76-301-B	1	Basket Bottom Clamp
8	335-416	4	Hexagon Nut 1/4-20	19	76-313-A	1	Basket Bottom Support
9	73-414-A	2	Spacer	20	346-416	4	Speed Nut 1/4
10	76-242-A	2	Pivot Latch	22	515-416-6	4	Machine Screw 1/4-20 x 3/8
11	76-254-A	2	End Cap	27	76-294-A	1	Pivot Rod

