

Parts and Service Manuals From:



On Line Materials for the Jan San Industry.

Since 1922

**Michigan Company Inc.
2011 N. High St.
Lansing, Mi 48906
(517) 484-9312**

[Http://www.Michco.Com](http://www.Michco.Com)

Email:Shop@Michco.com

Order parts on line or by Phone


Visa, MasterCard, Amex

Shipping to US addresses only.

Materials contained in this manual Copyright respective manufactuer, PDF version made exclusively by Michco for our customer's use only. Any other use of PDF version violates our PDF copyright.



SPARE PARTS



AS 28 AUTOMATIC

AUTOMATIC-SWEEPING-SCRUBBER


PF02331BC-3 ab SN from 98K191

This diagram shows the exploded view of a lawnmower, with components numbered 1 through 18. The components are as follows:

- 1: Upper housing / deck cover
- 2: Lower housing / deck
- 3: Blade guard / safety cover
- 4: Blade guard latch
- 5: Blade guard pivot pin
- 6: Blade guard pivot bracket
- 7: Blade guard pivot nut
- 8: Blade guard pivot pin
- 9: Blade guard pivot bracket
- 10: Blade guard pivot nut
- 11: Blade guard pivot pin
- 12: Blade guard pivot bracket
- 13: Blade guard pivot nut
- 14: Blade guard pivot pin
- 15: Blade guard pivot bracket
- 16: Blade guard pivot nut
- 17: Blade guard pivot pin
- 18: Blade guard pivot bracket

[illegible]

PUMP

[illegible]

This diagram shows an exploded view of a mechanical assembly. The components are identified by numbered callouts: 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 20, 21, 22, 23, 24, and 25. The assembly includes a main housing (20), a central shaft (11), a spring (12), and various fasteners and guides (1-10, 13-15, 21-25). The diagram illustrates the spatial relationship and assembly sequence of these parts.

[illegible]


pl1099 ab SN from 98J992

This diagram illustrates the exploded view of a mechanical assembly, likely a pump or valve mechanism. The components are identified by numbered callouts (1 through 28) pointing to their respective parts. The assembly includes a main housing (1), a central shaft (2), a piston or plunger (3), a valve or check valve (4), a spring (5), a seal or O-ring (6), a nut (7), a washer (8), a bolt (9), a pin (10), a bush (11), a sleeve (12), a pin (13), a pin (14), a pin (15), a pin (16), a pin (17), a pin (18), a pin (19), a pin (20), a pin (21), a pin (22), a pin (23), a pin (24), a pin (25), a pin (26), a pin (27), and a pin (28).

[illegible]

pl1101BC aa SN from 98L000

SUCTION UNIT

[illegible]

pl1239 aa SN from 98L000


This diagram shows an exploded view of a mechanical assembly. The components are numbered as follows:

- 1: A screw for the top plate.
- 2: A small pin or spacer.
- 3: A small washer or spacer.
- 4: A circular plate with a central hole.
- 5: A small pin or spacer.
- 6: A small pin or spacer.
- 7: A small pin or spacer.
- 8: A circular plate with a central hole.
- 9: A screw for the bottom plate.
- 11: A circular plate with a central hole.
- 12: A small pin or spacer.
- 13: A small pin or spacer.
- 12: A small pin or spacer (repeated).
- 14: A small pin or spacer.
- 15: A small pin or spacer.
- 16: A hook or latch.
- 17: A small pin or spacer.

[illegible]


pl1240 aa SN from 98L000

DESCRIPTION:	HEAD 71:MOTOR
--------------	---------------

[illegible]


pl1241 aa SN from 98L000

HEAD 71: FLAP and BOX

[illegible]

pl1244BC ab SN from 98L10

DESCRIPTION:	DRIVE AND BRAKE
--------------	-----------------


[illegible]

CODE:

pl1245 aa SN from 98L000


DESCRIPTION:

FRAME




REF.	CODE	DESCRIPTION	QT
1	SL17287	PLATE	2
2	SL14159	BELT	2
3	SL09642	FRAME	1
4	SL09933	STEERING COLUMN	1
5	SL04004	SCREW	4
6	SL06003	WASHER	8
7	SL05001	NUT	4
8	SL04222	SCREW	2
9	SL06014	WASHER	1
10	SL04148	SCREW	1
11	SL05032	NUT	4
12	SL07238	BEARING	1
13	SL14148	BRACKET / CLASP	1
14	SL03104	RUBBER SHIM	1
15	SL07237	BEARING	1
20	SL06011	WASHER	4
21	SL11095	RING	3
24	SL05070	NUT	1
25	SL08037	WHEEL / SMALL WHEEL	1
26	SL04236	SCREW	2
27	SL06089	WASHER	1
28	SL04083	SCREW	1
29	SL06002	WASHER	1
30	SL06053	WASHER	1

DESCRIPTION:	HEAD LIFTING UNIT
--------------	-------------------

[illegible]


TANK



REF.	CODE	DESCRIPTION	QT
1	SL17298	CAP	1
2	SL03212	FILTER	1
3	SL18206	FILTER	1
4	SL17293	NOZZLE	2
5	SL05048	NUT	1
6	SL06057	WASHER	1
7	SL06025	WASHER	1
8	SL03122	WASHER	1
9	SL04355	SCREW	1
10	SL05017	NUT	2
11	SL06023	WASHER	2
12	SL06022	WASHER	2
13	SL13045	DUCT LOCK	1
14	SL07184	BEARING	2
15	SL03122	WASHER	2
16	SL06039	WASHER	2
17	SL04324	SCREW	2
20	SL06015	WASHER	3
21	SL06001	WASHER	3
22	SL04135	SCREW	3
23	SL20015	KNOB (6 HANDWHEEL)	1
24	SL14237	CAP	1
25	SL03315	GASKET	1
26	SL14003	SLEEVE	1
27	SL06022	WASHER	1
28	SL04002	SCREW	1
29	SL19188	PIPE	1
30	SL13014	DUCT LOCK	2
31	SL04106	SCREW	2
32	SL05034	NUT	2
33	SL14063	CLAMP	1
34	MP03196	SHEATH 0.25	1
35	SL19286	PIPE	1
36	SL17307	INDICATOR	1
37	SL03264	GASKET	1
38	SL17385	COUPLING / CLUTCH	1
39	SL18233	UNION / CONNECTOR	1
40	SL23798	FLOAT SWITCH	1
41	SL19212	PIPE	1
42	SL14109	CLAMP	1
43	SL05059	NUT	1
44	SL23391	CABLE CLAMP	1
45	SL19224	PIPE	1
46	SL17364	COUPLING / CLUTCH	1
47	SL09617	FRAME	1

pl1249BC ab SN from 98J992

EXTERNAL PARTS



[illegible]

CODE:

pl1250 aa SN from 98L000


DESCRIPTION:

ELECTRIC UNIT 1




REF.	CODE	DESCRIPTION	QT
1	SL06001	WASHER	10
2	SL05005	NUT	8
3	SL23866	REMOTE CONTROL SWITCH	1
4	SL06002	WASHER	4
5	SL05004	NUT	8
6	SL06015	WASHER	8
7	SL23869	FUSE	1
8	SL06064	WASHER	4
9	SL04073	SCREW	2
10	SL04010	SCREW	2
11	SL06004	WASHER	4
12	SL04009	SCREW	2
13	SL23184J	TAP / OUTLET	1
14	SL17288	BOX	1
20	SL23867J	WIRING	1
21	SL23868	BRIDGE / JUMPER	1
22	SL23016	BRIDGE / JUMPER	1


DESCRIPTION:	ELECTRIC UNIT 2
--------------	-----------------

[illegible]

EXTERNAL
PARTS

[illegible]

SQUEEGEE



CODE:

pl1255 aa SN from 98L000

DESCRIPTION:

BRUSHES a340

POLYPROPYLENE - NYLON - NYLON
NYLON - NYLON


①

POLYSHING - POLIERBURSTERN
SORGHO - FIBRA - BASSINA


②

TYNEX - TYNEX - TYNEX
TYNEX - TYNEX


③




④

BLACK - SCHWARZ - NOIR
PAD - NERO


⑤

GREEN - GRUEN - VERT
VERDE - VERDE

⑥

YELLOW - GELB - JEUNE
AMARILLO - GIALLO

⑦



REF. CODE

DESCRIPTION

QT

1	AL02703	POLYPROPYLENE BRUSH
2	AL02707	POLYSHING BRUSH
3	AL02704	TYNEX BRUSHES
4	AL02705	PAD DRIVER
5	AL03510	STRIPPING PAD (BLACK)
6	AL03511	STRIPPING PAD (GREEN)
7	AL03512	STRIPPING PAD (YELLOW)

pl1271 ac SN from 98K191

This diagram shows an exploded view of a mechanical assembly. The components are identified by numbered callouts: 1, 2, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, and 15. The assembly includes a main frame (1), a vertical support (2), a horizontal bar (4), a central shaft (5), and various fasteners (6, 7, 8, 9, 10, 11, 12, 13, 14, 15). Dashed lines indicate the assembly path and the relative positions of the parts.


[illegible]

DESCRIPTION:

WIRING DIAGRAM

CODE:

WD27057 as SH from 58L000



WD27057-1 aa SN from 98L000

WE RESERVE THE RIGHT TO MODIFY SPECIFICATIONS WITHOUT NOTICE OR OBLIGATION



BETCO
1001 Brown Avenue - Toledo, Ohio 43607 - 1-800-777-9343