



Electronic Service Manuals

This electronic document is provided as a service to our customers. We do not create the contents of the information contained in this document. Should you have detailed questions pertaining to the information contained in this document, you may contact Michco, or the manufacturer which provided the original information in this electronic deliverable. Michco's only part in this electronic deliverable was the electronic assembly process. By providing this manual on line we are not guaranteeing parts availability.

You may contact Michco through the following methods:

Phone (517) 484-9312 or (800) 331-3339

2011 N. High St. -- Lansing, Michigan -- 48906

Fax: (517) 484-9836

Email: CustServe@Michco.com

Web site: www.Michco.Com

Parts Web site: www.FloorMachineParts.Com

Order Parts on Line at:

www.FloorMachineParts.Com

Directly to Parts & Service:

By Email: **Shop@Michco.com**


By Fax: (517) 702-2041

By Voice: Use numbers above.

Serving the Cleaning Industry Since 1922

Notice: All copyrighted material remains property of original owners, all trademarks are property of respective owners. Manuals are subject to Manufacturer's reproduction limitations. Originals or reproductions were provided by manufacturers through a request. We make no warranty as to the correctness of information provided in this document and you assume all risk. By placing these manuals on line we are not declaring our corporation to be an manufacturer authorized dealer or provider, please check our web site for authorized manufacturers we represent.


HANDLE ASSEMBLY



PARTS LIST

Ref. No.	Part No.	Qty. Per Unit	Description of Part	Ref. No.	Part No.	Qty. Per Unit	Description of Part
1	76-67-A	2	Handle Grip	15	76-179-A	2	Clamp Control
2	76-167-B	2	Handle	16	76-31-A	1	Control Rod Weldment
3	76-172-B	1	Cross Bar - Upper	17	515-8-8	2	Screw Rd. Hd. Mach. 8-32 x 1/2
4	65-416-24	2	Bolt Hex Hd. 1/4-20 x 1 1/2	18	365-8	2	Nut - Hex Lock 8-32
5	76-34-A	1	Lever	19	935-416	2	Washer - Spring Lock
6	67-521-A	1	Roll Pin	20	365-516	4	Nut - Hex Lock 5/16-18
7	69-416-24	3	Bolt Cont. Hd. 1/4-20 x 1 1/2	21	365-416	2	Nut - Hex Lock 1/4-20
8	69-416-16	1	Bolt Cont. Hd. 1/4-20 x 1	22	74-135-A	1	Spring
9	76-175-A	1	Bracket	23	76-178-A	4	Insert Ends
10	365-10	2	Nut - Hex Lock 10-24	24	76-173-B	1	Cross Bar Lower
11	62-95-A	1	Throttle Control Assembly 33-15-8-55	25	65-516-24	4	Bolt - Hex Hd. 5/16-18 x 1 1/2
12	517-10-18	2	Screw - Oval Hd. 10-24 x 1 1/8	26	335-416	4	Nut - Plain Hex 1/4-20
13	76-235-A	1	Control Rod (Upper)	27	76-169-B	2	Truss Brace
14	936-416	2	Washer - Int. Lock				


BLOWER ASSEMBLY



PARTS LIST

REF. NO.	PART NO.	QTY. PER UNIT	DESCRIPTION	REF. NO.	PART NO.	QTY. PER UNIT	DESCRIPTION
1	Engine	1		22	79-129-C	1	Pivot Ring
2	63-130-A	1	Key	23	73-119-A	1	Retainer, Fan <i>82-138-B-3, 60-716-16</i>
3	79-139-A	4	Spacer - Back Plate	24	935-716	1	Washer, Spring Lock
4	352-516	1	Nut, Acorn, 5/16-18	25	73-123-C	4	Anti-Wrap
5	79-94-A	1	Knob, 5/16-18	26	65-39-A	1	Bolt - Fan
6	945-516	1	Washer, 5/16	27	73-121-C	1	Grill Assembly
7	79-67-A	1	Spacer	28	410-6-402	6	Pop Rivet
8	79-51-A	1	Clamp	29	365-416	4	Nut - Hex Lock ¼-20
9	SA-776-C	1	Back Plate Weldment <i>80-316-A</i>	30	60-62-A	2	Roll Pin, ½ Dia. x ¾
10	935-616	5	Washer - Spring Lock ¾	31	73-372-A	1	Spring
11	65-616-24	4	Bolt - Hex Hd. ¾-16x1½	32	75-79-A	1	Knob
12	365-516	2	Nut, Hex, 5/16-18	33	75-80-A	2	Shaft, Retainer
13	935-516	2	Washer, Lock, 5/16	34	73-124-B	2	Exhaust, Side Plate
14	79-85-A	2	Spacer	35	73-406-A	1	Friction Disc
15	79-86-A	2	Guide, Roller <i>80-144-A</i>	36	73-125-B	2	Exhaust Deft. Weld.
16	945-516	2	Washer, 5/16	37	73-127-A	1	Connection Control Rod
17	65-516-30	2	Bolt, Hex Hd., 5/16-18x1¼	38	73-126-A	1	Link, Exhaust Deft.
18A	73-415-A	1	Spacer - Fan B/S Engine	39	65-416-12	4	Bolt, Hex Hd. ¼-20x¾
18B	74-154-A	1	Spacer - Fan - Kohler Engine	40	73-79-F	1	Blower Housing <i>SA-1199-C</i>
19	564-C-516-6	1	Screw Set 5/16-18x¾	41	365-10	6	Nut, Hex Lock 10-24
20	73-118-D	1	Fan	42	945-10	6	Washer, Flat
21	505-416-20	8	Screw - Flat Hd. ¼-20x1¼	43	515-10-10	6	Screw, Rd. Hd. 10-24x¾

CHASSIS AND ENGINE ASSEMBLY



NOTE: Wheels from Dico Corp. and Geneva Metal Wheel are used interchangeably. This table will enable you to correctly identify the parts you need.


	Dico Whl.	Geneva Whl.
Wheel	63-169-A	68-447-B
Wheel Bore	1-1/8	1-3/8
Bushing	63-313-A	67-03-A 69-222-A

PARTS LIST FOR CHASSIS AND ENGINE ASSEMBLY

Ref. No.	Part No.	Qty. Per Unit	Description of Part	Ref. No.	Part No.	Qty. Per Unit	Description of Part
1	73-102-A	1	Engine B/S <i>73-102-B-2</i>	11	68-313-A	2	Valve
	65-34-A	1	Kohler Eng.	12	68-447-B	2	Wheel
2	365-516	8	Nut - Hex Lock	13	65-521-A	1	Roll Pin
3	945-516	4	Washer - Flat	14	65-516-28	4	Bolt Hex Hd. 5/16 x 18 x 1 1/4
4	380-432-20	2	Cotter Pin 1/8 dia. x 1 1/4	15	127-BSA-913-C	1	SA-742C Roller Guard Assy.
5	945-1216	8	Washer Flat	16	73-363-A	1	Elbow-(Street) B/S Engine
6	67-03-A	4	Wheel Bearing <i>69-222-A</i>	17	Plug	1	Comes with Engine
7	68-312-A	2	Tires 5.30/4.50 x 6 <i>68-316-B</i>	18	57-81-A	1	Elbow-(Street) Kohler Engine
8	65-516-12	4	Bolt - Hex Hd. 5/16-18 x 1/4	19	69-125-A	1	1 x 45° Blk. St. Elbow
9	73-362-C	2	Handle Bracket	20	72-291-A	1	1 x 3 Blk. Pipe Nipple
10	73-360-C	1	Chassis Weldment <i>82-113-C</i>	21			SEE ROLLER DRAWING

ROLLER FOR BLOWER GUARD

SECTION 8
MODEL No. HC-798G
& HC-7980-K



Ref. Part No.	Part No.	Qty. Per Unit	Description of Part	Ref. Part No.	Part No.	Qty. Per Unit	Description of Part
1	66-436-A	1	Roller <i>SA-1390-B</i>	6	78-148-A	2	Spacer
2	55-161-A	2	Washer	8	65-516-20	2	Bolt-Hex Hd. $\frac{5}{16}$ -18 x 1 $\frac{1}{4}$
3	66-432-A	2	Bearing	9	935-516	2	Washer-Spring Lock $\frac{5}{16}$
4	78-147-A	1	Axle	10	365-516	2	Nut-Hex $\frac{5}{16}$ -18
5	74-130-A	2	Bracket				