



Electronic Service Manuals

This electronic document is provided as a service to our customers. We do not create the contents of the information contained in this document. Should you have detailed questions pertaining to the information contained in this document, you may contact Michco, or the manufacturer which provided the original information in this electronic deliverable. Michco's only part in this electronic deliverable was the electronic assembly process. By providing this manual on line we are not guaranteeing parts availability.

You may contact Michco through the following methods:

Phone (517) 484-9312 or (800) 331-3339

2011 N. High St. -- Lansing, Michigan -- 48906

Fax: (517) 484-9836

Email: CustServe@Michco.com

Web site: www.Michco.Com

Parts Web site: www.FloorMachineParts.Com

Order Parts on Line at:

www.FloorMachineParts.Com

Directly to Parts & Service:

By Email: **Shop@Michco.com**

By Fax: (517) 702-2041

By Voice: Use numbers above.

Serving the Cleaning Industry Since 1922



Notice: All copyrighted material remains property of original owners, all trademarks are property of respective owners. Manuals are subject to Manufacturer's reproduction limitations. Originals or reproductions were provided by manufacturers through a request. We make no warranty as to the correctness of information provided in this document and you assume all risk. By placing these manuals on line we are not declaring our corporation to be an manufacturer authorized dealer or provider, please check our web site for authorized manufacturers we represent.



2510/2550

36 Volt Dust Control Burnisher

Parts Manual



Model Part No.:

9003531 - 2510

9003532 - 2510 Complete

9006168 - 2510 w/AGM Complete

9006149 - 2510 China Model

9003535 - 2550

9003536 - 2550 Complete

9006170 - 2550 w/AGM Complete

609180 - 2550 Japan Model



For the latest Parts manuals and other
language Operator manuals, visit:


www.tennantco.com/manuals

North America / International

www.tennantco.com

9005432
Rev. 03 (04-2014)





Ref	Part No.	Serial Number	Description	Qty.
1	82681	(000000-)	Bracket Wldt, Lpg Mount	1
2	63810	(000000-)	Latch Assy, Lpg Tank Mtg, W/Nut	4
3	51839	(000000-)	Nut Adjustable, Lpg Tank Mtg	2
4	49263	(000000-)	Tie, Cable	3
5	82556	(000000- 001039)	Bracket, Vaporizer	1
6	54930	(000000-)	Vaporizer, LPG	1

HOW TO ORDER PARTS - See diagram above

Only use TENNANT Company supplied or equivalent parts. Parts and supplies may be ordered online, by phone, by fax or by mail.

Follow the steps below to ensure prompt delivery.

1. (A) Identify the machine model.
2. (B) Identify the machine serial number from the data label.
3. (C) Ensure the proper serial number is used from the parts list.
4. Identify the part number and quantity.
Do not order by page or reference numbers.
5. Provide your name, company name, customer ID number, billing and shipping address, phone number and purchase order number.
6. Provide detail shipping instructions.

- (D) ▽ - identifies an assembly
▲ - identifies parts included in assembly

Please fill out at time of installation for future reference.

Model No. - _____
 Serial No. - _____
 Machine Options - _____
 Sales Rep. - _____
 Sales Rep. phone no. - _____
 Customer ID Number - _____
 Installation Date - _____

Tennant Company

PO Box 1452
 Minneapolis, MN 55440 USA
 Phone: (800) 553- 8033 or
 (763) 513- 2850

www.tennantco.com

Tennant Company Shanghai

Building 3, No. 66, Tian Ying Road
 Shanghai Qingpu Industrial Zone
 Shanghai 201700
 People's Republic of China
 Phone: (86- 21) 6922- 5333
 www.tennantco.com.cn

TENNANT Company Japan

Sanka Bldg. 5F
 2- 9 Minami Saiwai- cho
 Saiwai- Ku
 Kawasaki, Kanagawa 212- 0016
 Tel: 044- 556- 1201
 Fax: 044- 556- 1202
 www.tennant.co.jp

Specifications and parts are subject to change without notice.

Copyright © 2008 - 2014
 TENNANT Company, Printed in USA.

ES	CÓMO SOLICITAR PIEZAS - Consulte el diagrama anterior. Utilice sólo las piezas suministradas por TENNANT Company o piezas equivalentes. Puede solicitar las piezas a través de internet, por teléfono, por fax o por correo. Siga los siguientes pasos para que la entrega sea rápida.	Rellene estos datos cuando realice la instalación para utilizarlos como referencia en el futuro. Nº modelo - _____ Nº serie - _____ Opciones de la máquina - _____ Vendedor - _____ Nº teléfono vendedor - _____ Nº cliente - _____ Fecha de instalación - _____
	1. (A) Indique el modelo de máquina. 2. (B) Indique el número de serie de la etiqueta de datos. 3. (C) Asegúrese de que indica el número de serie correcto de la lista de piezas. 4. Indique la cantidad y el número de la pieza. No realice el pedido indicando el número de página o el de referencia. 5. Incluya su nombre, el nombre de la empresa, el ID de cliente, las direcciones de envío y facturación, el número de teléfono y el número del pedido de compra. 6. Facilite instrucciones de envío.	

- (D) ▽ - identifica un conjunto
 ▲ - identifica piezas de un conjunto

FR	COMMENT COMMANDER DES PIÈCES DÉTACHÉES - Voir le schéma ci-dessus. Utilisez uniquement des pièces fournies par la société TENNANT ou équivalentes. Les pièces et fournitures peuvent être commandées en ligne, par téléphone, fax, ou par courrier. Suivez les étapes ci-dessous pour assurer une livraison rapide.	A remplir au moment de l'installation à titre de référence. Nº du modèle - _____ Nº de série - _____ Options de la machine - _____ Agent commercial - _____ Nº tél. de l'agent commercial - _____ Numéro d'identification client - _____ Date d'installation - _____
	1. (A) Identifiez le modèle de la machine. 2. (B) Identifiez le numéro de série de la machine, à partir de l'étiquette signalétique. 3. (C) Assurez-vous que le numéro de série correct est utilisé à partir de la liste de pièces détachées. 4. Identifiez le numéro de pièce et la quantité. Ne commandez pas par page ou numéros de référence. 5. Fournissez votre nom, le nom de votre société, votre numéro d'identification de client, l'adresse de facturation et d'expédition, le numéro de téléphone et le numéro du bon de commande. 6. Fournissez des instructions d'expédition détaillées.	

- (D) ▽ - identifie un assemblage
 ▲ - identifie les pièces composant l'assemblage

CN	如何订购部件 - 参见下表 仅使用 TENNANT 公司提供的或同等部件。部件和供应可以在线订购，通过电话、传真或邮件订购。 请遵循下面的步骤确保及时交付。	请在安装时填写供未来参考。 型号 - _____ 序列号 - _____ 机器选项 - _____ 销售代表 - _____ 销售代表电话号码 - _____ 客户 ID 编号 - _____ 安装日期 - _____
	1. (A) 确定机器型号。 2. (B) 从数据标签确定机器序列号。 3. (C) 确保使用部件列表中的正确序列号。 4. 确定部件号和数量。 不要按页面或参考编号订购。 5. 提供您的姓名、公司名称、客户 ID 号、付帐和送货地址、电话号码和采购单编号。 6. 提供详细的送货说明。	

- (D) ▽ - 确定组件
 ▲ - 确定组件中包含的组件

JP	パーツの発注方法 ? 上記の図を参照してください TENNANT 社製のパーツまたは同等品のみをお使いください。 パーツやサプライ品のご注文は、オンライン、電話、FAX、または手紙でお願いいたします。 確実にお届けできるように、以下の情報お知らせください。	後日確認できるように、設置時に記入してください。 モデルNo. - _____ シリアルNo. - _____ 製品のオプション - _____ 販売代理店 - _____ 販売代理店の電話番号 - _____ 顧客ID番号 - _____ 設置日 - _____
	1. (A) 製品のモデル名をお知らせください。 2. (B) 製品のデータラベルに印刷されているシリアル番号をお知らせください。 3. (C) パーツリストを参照して、シリアル番号が正しいかご確認ください。 4. パーツ番号と数量をお知らせください。マニュアル/カタログのページ番号や参照番号でのご注文はご遠慮ください。 5. お客様のお名前、会社名、顧客ID番号、請求/発送先住所、電話番号、注文書番号をお知らせください。 6. 発送に関するご希望があれば、明記してください。	

- (D) ▽ - アセンブリを示します
 ▲ - アセンブリに含まれるパーツを示します

GENERAL RECOMMENDED MAINTENANCE ITEMS	6
--	---

STANDARD PARTS

MAIN HOUSING GROUP	8
MAIN HOUSING GROUP - CONT'D	10
PAD DRIVER GROUP	12
WHEEL GROUP, DRIVE (2550 MODEL)	14
WHEEL GROUP, PUSH (2510 MODEL)	16
CONTROL CONSOLE GROUP (2550 MODEL)	18
CONTROL CONSOLE GROUP (2510 MODEL)	20
ELECTRICAL GROUP	22
BATTERY GROUP, LEAD ACID 12V/225AH	24
BATTERY GROUP, AGM 12V/234AH	25
OFF- BOARD BATTERY CHARGER GROUP ...	26
ON- BOARD BATTERY CHARGER GROUP	27
WIRING DIAGRAM 2550 MODEL WITH ON- BOARD CHARGER	28
LADDER DIAGRAM 2550 MODEL WITH ON- BOARD CHARGER	29
WIRING DIAGRAM 2550 MODEL WITHOUT ON- BOARD CHARGER	30
LADDER DIAGRAM 2550 MODEL WITHOUT ON- BOARD CHARGER	31

WIRING DIAGRAM 2510 MODEL WITH ON- BOARD CHARGER	32
LADDER DIAGRAM 2510 MODEL WITH ON- BOARD CHARGER	33
WIRING DIAGRAM 2510 MODEL WITHOUT ON- BOARD CHARGER	34
LADDER DIAGRAM 2510 MODEL WITHOUT ON- BOARD CHARGER	35
WIRE HARNESS, MAIN, 2550	36
WIRE HARNESS, MAIN, 2510	38

OPTIONS

HOURLY METER, EMERGENCY STOP AND KEYSWITCH KITS	40
LOW VOLT INTERRUPT KIT	41
AIR INLET GROUP (JAPAN MARKET)	42
PARKING BRAKE KIT	44

GENERAL RECOMMENDED MAINTENANCE

GENERAL RECOMMENDED MAINTENANCE ITEMS

	Part No.	Serial Number	Description	Qty.
	1014918	(00000000-	) Wheel, 03.0d 0.88w 0.31b, W/ Bshg, Rbr	4
	103001	(00000000-	) Caster, Swivel, 3.0d 1.3w, 4hole	1
	900210	(00000000-	) Filter, Bag, Cloth, Dust- Cntrl [Bur]	1
	1068845	(00000000-	) Bag, Vacuum, Paper [1pick=1pkg]	1
	49800	(00000000-	) Latch	2
	140962	(00000000-	) Latch, Cmpr, Spring, Knurled Knob, Pl	1
	1001518	(00000000-	) Cable, Glv .13d 020.5l .38eye /.38eye	1
▽	603398	(00000000-	) Motor, Ele, 36vdc 2000rpm 3.00hp	1
	621478	(00000000-	) Vr, Brush, Carbon [1pick=1pc]	4
▲	140628	(00000000-	) Key, Sq, 0.19 X 0.19, 1.00l	1
▽	1210491	(10679750-	) Driver Assy, Pad, 20d	1
▲	32506	(10679750-	) Device, Centering, Rh Pad Retainer	1
▲	1205787	(10679750-	) Collar, Locking, Pad Driver, 6.1"	1
▽	1041196	(10358740- 10679749	) Driver Assy, Pad, 20.0d, W/ Hub	1
▲	32506	(10358740- 10679749	) Device, Centering, Rh Pad Retainer	1
▽	1019931	(10219585- 10358739	) Driver Assy, Pad, 20.0d, W/ Hub	1
▲	370095	(10219585- 10358739	) Device, Centering, Clip On, TI [Gf Pp]	1
▽	605348	(00000000- 10219584	) Driver Assy, Pad, 20.0d, W/ Hub	1
▲▽	32506	(00000000- 10219584	) Device, Centering, Rh Pad Retainer	1
▲	100101	(00000000- 10219584	) Device, Centering, Rh, 1.50l [Rem Ylw]	1
	611788	(00000000-	) Pad, 20.0[Burnish, Hairblend, 1pick=1ctn]	1
	605103	(00000000-	) Skirt, Strip, 0.38 X 74.0	1
	603744	(00000000-	) Skirt, Felt, .18, 01.60w 72.00l [2510]	1
	230888	(00000000-	) Ring, Shield, Dust	1
	600195	(00000000-	) Seal, Dust- Cntrl, Motor Base	1
	613026	(00000000-	) Wheel, 08.0d 2.00w, 4- Hole Mtg, Blk[Nitr]	2
▽	1062315	(10474786-	) Transaxle, 36vdc, 116rpm, Mk400	1
	1007083	(10206962- 10474785	) Transaxle, 36vdc, 116rpm (Replaced by 1062315)	1
	612845	(00000000- 10206961	) Transaxle, 36vdc, 116rpm (Replaced by 1062315)	1
▲▽	612878	(00000000-	) Motor Kit, 36vdc, Replmt[612845 Trnsaxl]	1
▲▲	614166	(10206962-	) Brush Kit, Carbon, Transaxle, Replmt [4] (For 1007083 & 1062315 Transaxles)	1
	612883	(00000000- 10206961	) Brush Kit, Carbon, Transaxle, 24/36vdc (For 612845 Transaxle)	1
▲	612880	(00000000-	) Joint, Transaxle, Replmt	2
▲	1063591	(00000000-	) Retainer, Hub, Transaxle Wheel	2
▲	612875	(00000000-	) Key, Spcl, Transaxle Replmt	1
▲	612874	(00000000-	) Coupling, Transaxle, Replmt	1
	600952	(00000000-	) Actuator, 24vdc	1
	613026	(00000000-	) Wheel, 08.0d 2.00w, 4- Hole Mtg, Blk[Nitr]	2
	103066	(00000000-	) Wheel, 04.0d 1.50w 0.50b, Gray (Drive Model 2550)	2
	1062636	(00000000-	) Wheel, 8.0d 1.50w Polyurethane (Push Model 2510)	2
	1066506	(00000000-	) Grip, Handle, Rnd	2

▽ ASSEMBLY

▲ INCLUDED IN ASSEMBLY

GENERAL RECOMMENDED MAINTENANCE


GENERAL RECOMMENDED MAINTENANCE ITEMS

Ref.	Part No.	Serial Number	Description	Qty.
	1013132	(00000000-	) Switch, Lever, Snap Actn	1
	603848	(00000000-	) Gauge, Ammeter, Rt, 36vdc [Pressure]	1
	603399	(00000000-	) Switch, Push, Dpdt On/Off/Mom	1
	601107	(00000000-	) Switch, Rocker [Lighted]	2
	603847	(00000000-	) Gauge, Discharge, Battery, 36vdc	1
	1000821	(00000000-	) Controller, Propel, 36vdc	1
	601108	(00000000-	) Switch, Toggle, Mom	1
	606550	(00000000-	) Knob, Rnd, 0.92d 0.76l 0.25b, Plstc (Drive Model 2550)	1
	614003	(00000000-	) Switch, Snap, W/ Bump (Drive Model 2550)	2
	614003	(00000000-	) Switch, Snap, W/ Bump (Push Model 2510)	1
▽	602873	(00000000-	) Harness, Console, W/ Pot (Drive Model 2550)	1
▲	130776	(00000000-	) Potentiometer (Drive Model 2550)	1
▲	130775	(00000000-	) Potentiometer, 50k - Lockable (Drive Model 2550)	1
	605840	(00000000-	) Conduit, .75d X 30.0 [Loom]	1
	612766	(00000000-	) Solenoid, 36vdc [Cont Duty Bear]	1
	130733	(00000000-	) Contactor, Solenoid, 36vdc, Sp, No	1
	606404	(00000000-	) Diode Assy, W/ Ring Terminals	1
	604486	(00000000-	) Diode Assy [Spliced]	1
	605292	(00000000-	) Shunt	1
	76062	(00000000-	) Stand- Off, Wir, M6, Insulator, Panel	1
	1010555	(00000000-	) Gauge, Hourmeter, 14- 48vdc, Lcd, Rt (Japan Model)	1
	130781	(00000000-	) Circuitbreaker, 80.0a	1
	603487	(00000000-	) Circuitbreaker, 15.0a, Brush	1
▽	607475	(00000000-	) Switch, 12a [Keylock] (Japan Model)	1
▲	607821	(00000000-	) Key, Stl, Replmt (Japan Model)	1
	600437	(00000000-	) Switch, Snap, 15a, Rlr (Off- Board Charger)	1
▽	604502	(00000000-	) Brake Kit, Parking (Optional)	1
▽	604501	(00000000-	) Gauge Kit, Hourmeter [Spdgleams] (Optional)	1
▲	1010555	(00000000-	) Gauge, Hourmeter, 14- 48vdc, Lcd, Rt (Optional)	1
▽	612971	(00000000-	) E- Stop Kit [Spdgleam Plus R/S] (Optional)	1
▲	1011735	(00000000-	) Switch, Safety, Shutoff (Optional)	1
▽	612973	(00000000-	) Switch Kit, Key [Spdgleam R/S] (Optional)	1
▲▽	607475	(00000000-	) Switch, 12a [Keylock] (Optional)	1
▲▲	607821	(00000000-	) Key, Stl, Replmt (Optional)	1
▽	604642	(00000000-	) Interrupter Kit, Low Voltage [36v Batt] (Optional)	1
▲	600832	(00000000-	) Gauge, Discharge, Battery, 36vdc [Digit] (Optional)	1
▲	600831	(00000000-	) Lamp, Red, Blk Body, 36vdc W/ Push Nut (Optional)	1

▽ ASSEMBLY

▲ INCLUDED IN ASSEMBLY

MAIN HOUSING GROUP




MAIN HOUSING GROUP

	Ref.	Part No.	Serial Number	Description	Qty.
▽	1	614230	(00000000-	) Cover Assy, Battery, W/ Label, TI	1
	1	607603	(00000000-	) Cover, RM- TL, (Japan & China Model)	1
▲	2	120192	(00000000-	) Label, Logo, 07.1l White /Clr [Tennant]	1
▲	3	604297	(00000000-	) Label [Recess]	1
▲	4	1026386	(00000000-	) Label, Warning [Expl,Fire,Shk En/Fr/Es]	1
	4	613862	(00000000-	) Label, Warning, 6 X 2 Tj[Dc Brn/Scr/Ext] (Japan Model)	1
	4	1037349	(00000000-	) Label, Warning [Exp,Fre,Shk En/Fr/Es/Ch] (China Model)	1
	5	603268	(00000000-	) Hinge, .25pin .07 2.5w 16.0l, PI	1
	6	140524	(00000000-	) Nut, Hex, Lock, .25- 20, Kep	1
	7	1034731	(00000000-	) Screw, Hex, M6 X 1.00 X 16, Ss, Sems	2
	8	606684	(00000000-	) Stop, Motor	1
	9	604276	(00000000-	) Bracket, Stop, Motor	1
	10	1014918	(00000000-	) Wheel, 03.0d 0.88w 0.31b, W/ Bshg, Rbr	4
	11	74440	(00000000-	) Screw, Hex, M8 X 1.25 X 40, NI, Ss	4
	12	613136	(00000000-	) Deflector, Elbow, Rm- Nat [Magnatwin]	1
	13	100121	(00000000-	) Gasket, Elbow, .28, 03.50w 03.50l, Adh	1
	14	140011	(00000000-	) Washer, Flat, 0.21b 0.45d .03, Ss	4
	15	069760103	(00000000-	) Screw, Rnd, #10 X 1.00, Phl, PI [A]	4
	16	604295	(00000000-	) Plate, Latch	1
	17	1034731	(00000000-	) Screw, Hex, M6 X 1.00 X 16, Ss, Sems	2
	18	578769	(00000000-	) Label, Parts, Moving [Textless]	2
	19	140015	(00000000-	) Washer, Lock, Split, 0.31, Ss	4
	20	140027	(00000000-	) Washer, Flat, 0.35b 0.75d .04, Ss	8
	21	15675	(00000000-	) Screw, Hex, M8 X 1.25 X 16, Ss	4
	22	103001	(00000000-	) Caster, Swivel, 3.0d 1.3w, 4hole	1
	23	608575	(00000000-	) Cover, Bag, Dust, TI	1
	24	140706	(00000000-	) Rivet, Blind, .125d, PI	2
	25	140962	(00000000-	) Latch, Cmpr, Spring, Knurled Knob, PI	1
	26	603269	(00000000-	) Hinge, .12pin .06 2.0w 13.0l, Yel PI	1
	27	1034731	(00000000-	) Screw, Hex, M6 X 1.00 X 16, Ss, Sems	7
	28	140000	(00000000-	) Washer, Flat, 0.28b 0.62d .04, Ss	7
	29	08712	(00000000-	) Nut, Hex, Lock, M6 X 1.00, NI, Ss	3
	30	900210	(00000000-	) Filter, Bag, Cloth, Dust- Cntrl [Bur]	1
	30	1068845	(00000000-	) Bag, Vacuum, Paper [1pick=1pkg]	1
	31	608149	(00000000-	) Label [Tennant 2550]	2
	31	608150	(00000000-	) Label, Model [2510]	2
	32	607600	(00000000-	) Frame, Chassis, Rm- TI, Trimmed [2510/50]	1
	33	49800	(00000000-	) Latch	2
	34	200070340	(00000000-	) Screw, Pan, Phl, M4 X 0.70 X 8, PI	8
	35	02938	(00000000-	) Washer, Lock, Int, 08, Ss	8

▽ ASSEMBLY

▲ INCLUDED IN ASSEMBLY


MAIN HOUSING GROUP - CONT'D



MAIN HOUSING GROUP - CONT'D

Ref.	Part No.	Serial Number	Description	Qty.
36	15675	(00000000-	) Screw, Hex, M8 X 1.25 X 16, Ss	1
37	140015	(00000000-	) Washer, Lock, Split, 0.31, Ss	5
38	140027	(00000000-	) Washer, Flat, 0.35b 0.75d .04, Ss	5
39	611418	(00000000-	) Sleeve, P/M, 0.31b 0.44d 0.1l, Pl	1
40	604637	(00000000-	) Support, Cover	1
41	230661	(00000000-	) Plate, Hsng, Lock Cntrl	2
42	15675	(00000000-	) Screw, Hex, M8 X 1.25 X 16, Ss	4
43	604304	(00000000-	) Label, Hzrd, Battery Connections	1
44	1034731	(00000000-	) Screw, Hex, M6 X 1.00 X 16, Ss, Sems	8
45	1001518	(00000000-	) Cable, Glv .13d 020.5l .38eye /.38eye	1
46	1001553	(00000000-	) Bushing, Sleeve, 0.25b 0.36d 0.16l, Stl	2
47	1034731	(00000000-	) Screw, Hex, M6 X 1.00 X 16, Ss, Sems	2

PAD DRIVER GROUP




PAD DRIVER GROUP

Ref.	Part No.	Serial Number	Description	Qty.
	1	604278	(00000000-) Bracket, Spring, Motor	1
	2	604333	(00000000-) Spring, Extn, 0.50od 0.06wir 04.0l	1
	3	08712	(00000000-) Nut, Hex, Lock, M6 X 1.00, NI, Ss	1
	4	09258	(00000000-) Screw, Pan, Phl, M6 X 1.00 X 40, 4.8	1
	5	140890	(00000000-) Screw, Trs, Phl, 10- 24 X 0.50, Ss	1
▽	6	140323	(00000000-) Clamp, Cable, Nyl, 0.50d, Nat	1
	7	603398	(00000000-) Motor, Ele, 36vdc 2000rpm 3.00hp	1
		621478	(00000000-) Vr, Brush, Carbon [1pick=1pc]	4
▲	8	140628	(00000000-) Key, Sq, 0.19 X 0.19, 1.00l	1
▲	9	130162	(00000000-) Terminal, Ring, .25stud 08ga [Vi Rd]	2
	10	1021186	(00000000-) Bracket, Mtg, Motor	1
	11	09745	(00000000-) Screw, Hex, M12 X 1.75 X 25, Ss	2
	12	140024	(00000000-) Washer, Lock, Split, 0.50, Ss	2
	13	140045	(00000000-) Washer, Flat, 0.51b 1.25d .06, Ss	4
	14	603273	(00000000-) Arm, Lift, Motor	2
	15	140139	(00000000-) Sleeve, P/M, 0.50b 0.63d 0.3l, PI	2
	16	36643	(00000000-) Nut, Hex, Lock, .38- 16, NI, Thin	4
	17	140028	(00000000-) Washer, Flat, 0.42b 1.00d .05, Ss	4
	18	20536- 2	(00000000-) Washer, Flat, 0.50b 1.00d .03, Nyl	8
	19	600191	(00000000-) Sleeve, P/M, 0.38b 0.50d 0.2l, PI	4
	20	140028	(00000000-) Washer, Flat, 0.42b 1.00d .05, Ss	4
	21	140017	(00000000-) Washer, Lock, Split, 0.38, Ss	4
	22	02994	(00000000-) Screw, Hex, .38- 16 X 0.75, Ss	4
	23	069760023	(00000000-) Washer, Flat, 0.77b 1.26d .03, Ss	1
▽	24	1019931	(10219585- 10358739) Driver Assy, Pad, 20.0d, W/ Hub	1
▲	25	370095	(10219585- 10358739) Device, Centering, Clip On, TI [Gf Pp]	1
	26	611788	(00000000-) Pad, 20.0[Burnish, Hairblend,1pick=1ctn]	1
▽	27	605348	(00000000- 10219584) Driver Assy, Pad, 20.0d, W/ Hub	1
▲▽	28	32506	(00000000- 10219584) Device, Centering, Rh Pad Retainer	1
▲	29	100101	(00000000- 10219584) Device, Centering, Rh, 1.50l [Rem Ylw]	1
	30	32505	(00000000- 10219584) Washer, Flat, 92b 156d 2.6l, Pad Driver	1
	31	41186	(00000000-) Washer, Flat, Belleville, .31	1
	32	140203	(00000000-) Screw, Hex, .31- 24 X 1.25, PI	1
	33	605103	(00000000-) Skirt, Strip, 0.38 X 74.0	1
	34	603744	(00000000-) Skirt, Felt, .18, 01.60w 72.00l [2510]	1
	35	230913	(00000000-) Clamp, Screw [F/ Skirt Banding]	1
	36	140340	(00000000-) Screw, Pan, Phl, 10- 24 X 0.62, Ss[Typ25]	6
	37	230888	(00000000-) Ring, Shield, Dust	1
	38	600195	(00000000-) Seal, Dust- Cntrl, Motor Base	1
	39	600385	(00000000-) Screw, Pan, Phl, M6 X 1.00 X 20, Ss	1
	40	25732	(00000000-) Washer, Flat, 0.36b 1.25d .09, PI	1
▽	41	1041196	(10358740- 10679749) Driver Assy, Pad, 20.0d, W/ Hub	1
▲	42	32506	(10358740- 10679749) Device, Centering, Rh Pad Retainer	1
▽	41	1210491	(10679750-) Driver Assy, Pad, 20d	1
▲	42	32506	(10679750-) Device, Centering, Rh Pad Retainer	1
▲	43	1205787	(10679750-) Collar, Locking, Pad Driver, 6.1"	1

▽ ASSEMBLY

▲ INCLUDED IN ASSEMBLY

WHEEL GROUP, DRIVE (2550 MODEL)




WHEEL GROUP, DRIVE (2550 MODEL)

Ref.	Part No.	Serial Number	Description	Qty.		
1	603277	(00000000-	) Frame Wldt, Clr Pl [2550/Speedglm]	1		
2	140431	(00000000-	) Spring, Extn, 1.00od 0.01wir 05.0l, Mw	4		
3	611023	(00000000-	) Sleeve, Spring, Rbr	2		
4	613026	(00000000-	) Wheel, 08.0d 2.00w,4- Hole Mtg,Blk[Nitr]	2		
5	602881	(00000000-	) Bracket, Mtg, Transaxle, Pl [2550/Spdgl]	2		
▽	6	140028	(00000000-	) Washer, Flat, 0.42b 1.00d .05, Ss	4	
	7	140333	(00000000-	) Washer, Lock, Split, M10, Ss	6	
	8	06963	(00000000-	) Screw, Hex, M10 X 1.50 X 60, 8.8	4	
	9	604293	(00000000-	) Spacer, Shim, .75w 4.0l .06th, 2sl, Pl	1	
	10	1062315	(10474786-	) Transaxle, 36vdc, 116rpm, Mk400	1	
▲▽	10	1007083	(10206962- 10474785	) Transaxle, 36vdc, 116rpm (Replaced by 1062315)	1	
	10	612845	(00000000- 10206961	) Transaxle, 36vdc, 116rpm (Replaced by 1062315)	1	
	11	612878	(00000000-	) Motor Kit, 36vdc, Replmt[612845 Trnsaxl]	1	
	▲▲	12	614166	(10206962-	) Brush Kit, Carbon, Transaxle, Replmt [4] (For 1007083 & 1062315 Transaxles)	1
	12	612883	(00000000- 10206961	) Brush Kit, Carbon, Transaxle, 24/36vdc (For 612845 Transaxle)	1	
▲	13	612880	(00000000-	) Joint, Transaxle, Replmt	2	
▲	14	1063591	(00000000-	) Retainer, Hub, Transaxle Wheel	2	
▲	15	612875	(00000000-	) Key, Spcl, Transaxle Replmt	1	
▲	16	32982	(00000000-	) Washer, Lock, Int, 0.25	2	
▲	17	33951	(10206962-	) Screw, Soc, M6 X 1.00 X 20, 12.9	2	
▲	17	01681	(00000000- 10206961	) Screw, Soc, .25- 20 X 0.75, Al	2	
	18	612874	(00000000-	) Coupling, Transaxle, Replmt	1	
	19	609450	(00000000-	) Bracket Wldt, Spring	1	
	20	600952	(00000000-	) Actuator, 24vdc	1	
	21	604076	(00000000-	) Pin, Clevis, M10d X 28, Pl	2	
22	86866	(00000000-	) Pin, Cotter, Hair, 0.38d .072 Wir	2		
23	130133	(00000000-	) Terminal, Mal, .25 22- 18ga Red, F- Ins	2		
24	603267	(00000000-	) Plate, Arm, Pivot	2		
25	069762098	(00000000-	) Screw, Flt, M6 X 1.0 X 16, Phl, Ss	2		
26	103066	(00000000-	) Wheel, 04.0d 1.50w 0.50b, Gray	2		
27	140045	(00000000-	) Washer, Flat, 0.51b 1.25d .06, Ss	2		
28	603274	(00000000-	) Axle, .6d X 08.75l, Rear [2510/2550]	1		
29	140144	(00000000-	) Sleeve, P/M, 0.38b 0.50d 0.4l, Pl	2		
30	140028	(00000000-	) Washer, Flat, 0.42b 1.00d .05, Ss	4		
31	140017	(00000000-	) Washer, Lock, Split, 0.38, Ss	2		
32	69225	(00000000-	) Screw, Hex, .38- 16 X 1.00, Ss	2		
33	140829	(00000000-	) Screw, Pan, Phl, 06- 32 X 1.00, Ss	2		
34	1013132	(00000000-	) Switch, Lever, Snap Actn	1		
35	140539	(00000000-	) Nut, Hex, Lock, #06- 32, Kep, Ss	2		
36	140000	(00000000-	) Washer, Flat, 0.28b 0.62d .04, Ss	8		
37	41169	(00000000-	) Nut, Hex, Lock, .25- 20, NI, Ss	8		
38	09291	(00000000-	) Screw, Hex, M10 X 1.50 X 20, Ss	2		

▽ ASSEMBLY

▲ INCLUDED IN ASSEMBLY


WHEEL GROUP, PUSH (2510 MODEL)



WHEEL GROUP, PUSH (2510 MODEL)

Ref.	Part No.	Serial Number	Description	Qty.
1	603277	(00000000-	) Frame Wldt, Clr Pl [2550/Speedglm]	1
2	1062636	(00000000-	) Wheel, 8.0d 1.50w Polyurethane	2
3	604293	(00000000-	) Spacer, Shim, .75w 4.0l .06th, 2sl, Pl	1
4	603275	(00000000-	) Axle Wldt, 0.75d X 19.12l [2510]	1
5	140333	(00000000-	) Washer, Lock, Split, M10, Ss	6
6	06963	(00000000-	) Screw, Hex, M10 X 1.50 X 60, 8.8	4
7	150210	(00000000-	) Plug, Cap, Blk	2
8	15675	(00000000-	) Screw, Hex, M8 X 1.25 X 16, Ss	2
9	140015	(00000000-	) Washer, Lock, Split, 0.31, Ss	2
10	140048	(00000000-	) Washer, 0.312	2
11	140047	(00000000-	) Washer, Flat, 0.75b 1.25d .06, Ss	2
12	140431	(00000000-	) Spring, Extn, 1.00od 0.01wir 05.0l, Mw	4
13	609450	(00000000-	) Bracket Wldt, Spring	1
14	600952	(00000000-	) Actuator, 24vdc	1
15	604076	(00000000-	) Pin, Clevis, M10d X 28, Pl	2
16	86866	(00000000-	) Pin, Cotter, Hair, 0.38d .072 Wir	2
17	130133	(00000000-	) Terminal, Mal, .25 22- 18ga Red, F- Ins	2
18	603267	(00000000-	) Plate, Arm, Pivot	2
19	069762098	(00000000-	) Screw, Flt, M6 X 1.0 X 16, Phl, Ss	2
20	103066	(00000000-	) Wheel, 04.0d 1.50w 0.50b, Gray	2
21	140045	(00000000-	) Washer, Flat, 0.51b 1.25d .06, Ss	2
22	603274	(00000000-	) Axle, .6d X 08.75l, Rear [2510/2550]	1
23	140144	(00000000-	) Sleeve, P/M, 0.38b 0.50d 0.4l, Pl	2
24	140028	(00000000-	) Washer, Flat, 0.42b 1.00d .05, Ss	8
25	140017	(00000000-	) Washer, Lock, Split, 0.38, Ss	2
26	69225	(00000000-	) Screw, Hex, .38- 16 X 1.00, Ss	2
27	140829	(00000000-	) Screw, Pan, Phl, 06- 32 X 1.00, Ss	2
28	1013132	(00000000-	) Switch, Lever, Snap Actn	1
29	140539	(00000000-	) Nut, Hex, Lock, #06- 32, Kep, Ss	2
30	30013	(00000000-	) Washer, Flat, 0.31, Fendr	2
31	09291	(00000000-	) Screw, Hex, M10 X 1.50 X 20, Ss	2
32	611023	(00000000-	) Sleeve, Spring, Rbr	2

CONTROL CONSOLE GROUP (2550 MODEL)




CONTROL CONSOLE GROUP (2550 MODEL)

Ref.	Part No.	Serial Number	Description	Qty.
1	1066506	(00000000-	) Grip, Handle, Rnd	2
2	605351	(00000000-	) Bushing, .88, Blk [10]	1
3	604402	(00000000-	) Tube, Handle	1
4	603848	(00000000-	) Gauge, Ammeter, Rt, 36vdc [Pressure]	1
5	604930	(00000000-	) Screw, Trs, M5 X 0.80 X 10, Phl, Pl, NI	4
6	613086	(00000000-	) Harness, Main, Drive [2550]	1
	605840	(00000000-	) Conduit, .75d X 30.0 [Loom]	1
7	603757	(00000000-	) Panel, Switch [Spdgleam Plus]	1
8	603399	(00000000-	) Switch, Push, Dpdt On/Off/Mom	1
9	601107	(00000000-	) Switch, Rocker [Lighted]	2
10	603847	(00000000-	) Gauge, Discharge, Battery, 36vdc	1
11	1000821	(00000000-	) Controller, Propel, 36vdc	1
12	02850	(00000000-	) Nut, Hex, Lock, M4 X 0.70, NI	4
13	630261	(00000000-	) Tube, 0.19id 0.31od 00.5l, Alm	2
14	630128	(00000000-	) Heatsink, 11ga Alm, 104 X 120	1
15	607556	(00000000-	) Housing, Cntrl, Rm- TI, Trimmed	1
16	601108	(00000000-	) Switch, Toggle, Mom	1
17	130753	(00000000-	) Boot, Switch, .47- 32 , 1.00l, Blk [2550]	1
18	08712	(00000000-	) Nut, Hex, Lock, M6 X 1.00, NI, Ss	2
19	140045	(00000000-	) Washer, Flat, 0.51b 1.25d .06, Ss	2
20	140351	(00000000-	) Screw, Hex, M12 X 1.75 X 70, Pl	2
21	630304	(00000000-	) Screw, Flt, Phl, M4 X 0.70 X 35, 4.8	2
22	230715	(00000000-	) Tube, Handle, Adj [Ctx]	1
23	230649	(00000000-	) Pin, Handle, Adjmt	2
24	230710	(00000000-	) Pin, Handle, Lock	2
25	140415	(00000000-	) Spring, Lock Pin	1
26	140155	(00000000-	) Bushing, .48 X .62 X 2.00	2
27	606550	(00000000-	) Knob, Rnd, 0.92d 0.76l 0.25b, Plstc	1
28	140024	(00000000-	) Washer, Lock, Split, 0.50, Ss	2
29	602886	(00000000-	) Pin, Spring, Hanger, .31- 18thrd X .94,Pl	1
30	605812	(00000000-	) Spring, Extn	1
31	1048847	(00000000-	) Screw, Hex, 06- 32 X 1.75 Fl, Ss	2
32	140019	(00000000-	) Washer, Lock, Ext, 06	2
33	27098	(00000000-	) Bracket, Switch	1
34	614003	(00000000-	) Switch, Snap, W/ Bump	2
35	140552	(00000000-	) Nut, Hex, Lock, #10- 24, NI, Ss	1
36	140000	(00000000-	) Washer, Flat, 0.28b 0.62d .04, Ss	5
37	25671	(00000000-	) Mount, Switch	1
38	140890	(00000000-	) Screw, Trs, Phl, 10- 24 X 0.50, Ss	1
39	603830	(00000000-	) Plate, Guard, Switch	1
40	608322	(00000000-	) Screw, Trs, M6 X 1.00 X 16, Phl, Ss	2
▽	41	602873	) Harness, Console, W/ Pot	1
▲	42	130776	) Potentiometer	1
▲	43	130775	) Potentiometer, 50k - Lockable	1
44	140540	(00000000-	) Nut, Hex, Std, #06- 32, Ss	2
45	605094	(00000000-	) Collar, Handle	2
46	140859	(00000000-	) Screw, Set, .25- 20 X 0.25, Soc	2
47	606549	(00000000-	) Label, Spd Cntrl	1

▽ ASSEMBLY

▲ INCLUDED IN ASSEMBLY


CONTROL CONSOLE GROUP (2510 MODEL)



CONTROL CONSOLE GROUP (2510 MODEL)

Ref.	Part No.	Serial Number	Description	Qty.
1	1066506	(00000000-	) Grip, Handle, Rnd	2
2	605351	(00000000-	) Bushing, .88, Blk [10]	1
3	604402	(00000000-	) Tube, Handle	1
4	603848	(00000000-	) Gauge, Ammeter, Rt, 36vdc [Pressure]	1
5	604930	(00000000-	) Screw, Trs, M5 X 0.80 X 10, Phl, Pl, NI	4
6	140859	(00000000-	) Screw, Set, .25- 20 X 0.25, Soc	2
7	604269	(00000000-	) Panel, Switch [Spdgleam]	1
8	603399	(00000000-	) Switch, Push, Dpdt On/Off/Mom	1
9	601107	(00000000-	) Switch, Rocker [Lighted]	1
10	603847	(00000000-	) Gauge, Discharge, Battery, 36vdc	1
11	607604	(00000000-	) Housing, Cntrl, Rm- TI, Trimmed	1
12	08712	(00000000-	) Nut, Hex, Lock, M6 X 1.00, NI, Ss	2
13	140045	(00000000-	) Washer, Flat, 0.51b 1.25d .06, Ss	2
14	140351	(00000000-	) Screw, Hex, M12 X 1.75 X 70, Pl	2
15	230715	(00000000-	) Tube, Handle, Adj [Ctx]	1
16	230649	(00000000-	) Pin, Handle, Adjmt	2
17	230710	(00000000-	) Pin, Handle, Lock	2
18	140415	(00000000-	) Spring, Lock Pin	1
19	140155	(00000000-	) Bushing, .48 X .62 X 2.00	2
20	140024	(00000000-	) Washer, Lock, Split, 0.50, Ss	2
21	602886	(00000000-	) Pin, Spring, Hanger, .31- 18thrd X .94,Pl	1
22	605812	(00000000-	) Spring, Extn	1
23	1048848	(00000000-	) Screw, Hex, 06- 32 X 1.00 Fl, S/S	2
24	140019	(00000000-	) Washer, Lock, Ext, 06	2
25	27098	(00000000-	) Bracket, Switch	1
26	614003	(00000000-	) Switch, Snap, W/ Bump	1
27	140552	(00000000-	) Nut, Hex, Lock, #10- 24, NI, Ss	1
28	140000	(00000000-	) Washer, Flat, 0.28b 0.62d .04, Ss	5
29	25671	(00000000-	) Mount, Switch	1
30	140890	(00000000-	) Screw, Trs, Phl, 10- 24 X 0.50, Ss	1
31	603830	(00000000-	) Plate, Guard, Switch	1
32	608322	(00000000-	) Screw, Trs, M6 X 1.00 X 16, Phl, Ss	2
33	606539	(00000000-	) Harness, Main, Push [2510]	1
	605840	(00000000-	) Conduit, .75d X 30.0 [Loom]	1
34	140540	(00000000-	) Nut, Hex, Std, #06- 32, Ss	2
35	605094	(00000000-	) Collar, Handle	2

ELECTRICAL GROUP




ELECTRICAL GROUP

Ref.	Part No.	Serial Number	Description	Qty.
1	604939	(00000000-	) Panel, Cntrl, Rear	1
2	609969	(00000000-	) Plug, Hole, Hourmeter, Blk	2
3	069762009	(00000000-	) Grommet, 25.4d X 03mm Th, Grv	2
4	130175	(00000000-	) Plug, Hole, Rnd, 0.75d, Blk	1
5	605823	(00000000-	) Seal, Org .926id X .99600	2
6	612766	(00000000-	) Solenoid, 36vdc [Cont Duty Bear]	1
7	24196	(00000000-	) Screw, Pan, Phl, M5 X 0.80 X 20, Ss	4
8	608322	(00000000-	) Screw, Trs, M6 X 1.00 X 16, Phl, Ss	4
9	08712	(00000000-	) Nut, Hex, Lock, M6 X 1.00, NI, Ss	4
10	140000	(00000000-	) Washer, Flat, 0.28b 0.62d .04, Ss	6
11	606404	(00000000-	) Diode Assy, W/ Ring Terminals	1
12	604486	(00000000-	) Diode Assy [Spliced]	1
13	130733	(00000000-	) Contactor, Solenoid, 36vdc, Sp, No	1
14	1034731	(00000000-	) Screw, Hex, M6 X 1.00 X 16, Ss, Sems	3
15	604271	(00000000-	) Bracket Wldt, Chassis, Ele	1
16	130781	(00000000-	) Circuitbreaker, 80.0a	1
17	603487	(00000000-	) Circuitbreaker, 15.0a, Brush	1
18	09739	(00000000-	) Nut, Hex, Lock, M5 X 0.80, NI, Ss	2
19	140524	(00000000-	) Nut, Hex, Lock, .25- 20, Kep	2
20	604292	(00000000-	) Cable, 04ga 06.0l Blk .25ring /.25ring	1
21	604940	(00000000-	) Plug, Hole, Rnd, 0.31h 0.3l, Blk Nyl	1
22	01696	(00000000-	) Screw, Hex, .25- 20 X 0.50, Ss	2
23	09739	(00000000-	) Nut, Hex, Lock, M5 X 0.80, NI, Ss	2
24	605292	(00000000-	) Shunt	1
25	604290	(00000000-	) Cable, 04ga 27.0l Blk .25ring /.31ring	1
26	140016	(00000000-	) Washer, Lock, Split, 0.25, Ss	2
27	604289	(00000000-	) Cable, 04ga 46.0l Red .31ring /.38ring	1
28	76062	(00000000-	) Stand- Off, Wir, M6, Insulator, Panel	1
29	604291	(00000000-	) Cable, 04ga 05.5l Blk .25ring /.31ring	1
30	130161	(00000000-	) Plug, Hole, Rnd, 0.88d, Blk	1
31	140011	(00000000-	) Washer, Flat, 0.21b 0.45d .03, Ss	4
32	140026	(00000000-	) Washer, Flat, 0.16b 0.38d .05, Pl, 06	1
33	140340	(00000000-	) Screw, Pan, Phl, 10- 24 X 0.62, Ss[Typ25]	1
34	604930	(00000000-	) Screw, Trs, M5 X 0.80 X 10, Phl, Pl, NI	4
35	1010555	(00000000-	) Gauge, Hourmeter, 14- 48vdc, Lcd, Rt (Japan Model)	1
▽	36	607475	(00000000-) Switch, 12a [Keylock] (Japan Model)	1
▲	37	607821	(00000000-) Key, Stl, Replmt (Japan Model)	1
	38	604793	(00000000-) Label, Keyswitch On(1) / Off(0) (Japan Model)	1

▽ ASSEMBLY


▲ INCLUDED IN ASSEMBLY

BATTERY GROUP, LEAD ACID 12V/225AH




Ref.	Part No.	Serial Number	Description	Qty.
1	1070591	(00000000-	) Battery, Wet, 12vdc 0225ah	3
2	223364	(00000000-	) Cable, 04ga 18.0l Blk .34ring /.34ring	2
3	68872	(00000000-	) Boot, Terminal, Battery, 02-01ga, Blk	6
4	611022	(00000000-	) Gasket, Ure, .25, 03.50w 15.25l, Adh	2
5	604298	(00000000-	) Tray, Battery, Rm- Blk, Trim[2510/Spdglm]	1

BATTERY GROUP, AGM 12V/234AH




Ref.	Part No.	Serial Number	Description	Qty.
1	1053427	(00000000-	) Battery, 12vdc 0234ah Agm	3
2	223364	(00000000-	) Cable, 04ga 18.0l Blk .34ring /.34ring	2
3	68872	(00000000-	) Boot, Terminal, Battery, 02- 01ga, Blk	6
4	611022	(00000000-	) Gasket, Ure, .25, 03.50w 15.25l, Adh	2
5	604298	(00000000-	) Tray, Battery, Rm- Blk, Trim[2510/Spdglm]	1

OFF-BOARD BATTERY CHARGER GROUP




Ref.	Part No.	Serial Number	Description	Qty.
1	604270	(00000000-	) Bracket, Plug, Chrgr	1
2	140539	(00000000-	) Nut, Hex, Lock, #06- 32, Kep, Ss	2
3	603331	(00000000-	) Spacer, Plug, Chrgr	1
4	604288	(00000000-	) Wire Assy, 10ga /2 .31ring /.38ring 050a	1
5	140019	(00000000-	) Washer, Lock, Ext, 06	2
6	140829	(00000000-	) Screw, Pan, Phl, 06- 32 X 1.00, Ss	2
7	1034731	(00000000-	) Screw, Hex, M6 X 1.00 X 16, Ss, Sems	2
8	600437	(00000000-	) Switch, Snap, 15a, Rlr	1
9	601359	(00000000-	) Plate, Backing, Switch	1
10	578403000	(00000000-	) Screw, Pan, M3 X 0.5 X 20, Phl, Pl	2
11	601127000	(00000000-	) Washer, Flat, 0.15b 0.31d .02, Pl, M3	1
12	579211	(00000000-	) Nut, Hex, Lock, M3 X 0.50, NI, Ss	2
13	469760868	(00000000-	) Charger, 36vac, 25a [F/ 215- 305ah]	1

ON-BOARD BATTERY CHARGER GROUP




Ref.	Part No.	Serial Number	Description	Qty.
1	1037826	(00000000-	) Charger, 36vdc, 21a Var Vac [Onboard]	1
1	1053426	(00000000-	) Charger, 36vdc, 21a Var Vac [Onboard Agm]	1
2	200315016	(00000000-	) Washer, Flat, M5.3b X 15.0d X 1.6, PI	4
3	07789	(00000000-	) Nut, Hex, Flng, M5 X 0.80	8
4	019680127	(00000000-	) Washer, Flat, 6.2mm Id X 22.0mm Od X 1.9	4
5	575732	(00000000-	) Screw, Hex, M5 X 0.80 X 40	4
6	86366	(00000000-	) Relay, 36vdc, 030a, Spdt [Midland]	1
7	140026	(00000000-	) Washer, Flat, 0.16b 0.38d .05, PI, 06	4
8	579211	(00000000-	) Nut, Hex, Lock, M3 X 0.50, NI, Ss	2
9	200070266	(00000000-	) Screw, Pan, Phl, M3 X 0.50 X 16, PI	2
10	230920.BK	(00000000-	) Hook, Cord, Blk [Boss]	2
11	1009324	(00000000-	) Screw, Pan, Phl, 10- 16 X 0.50,Blk[Typ17]	4
12	1017079	(00000000-	) Cord, Extn, 16ga /3, 10ft [Sjt]	1

WIRING DIAGRAM 2550 MODEL WITH ON-BOARD CHARGER




DWG # 1042608


LADDER DIAGRAM 2550 MODEL WITH ON-BOARD CHARGER



WIRING DIAGRAM 2550 MODEL WITHOUT ON-BOARD CHARGER




LADDER DIAGRAM 2550 MODEL WITHOUT ON-BOARD CHARGER



Tennant 2510/2550 (02-2011)




LADDER DIAGRAM 2510 MODEL WITH ON-BOARD CHARGER




DWG #1042617


Tennant 2510/2550 (08-2008)



LADDER DIAGRAM 2510 MODEL WITHOUT ON-BOARD CHARGER



WIRE HARNESS, MAIN, 2550




WIRE HARNESS, MAIN, 2550 - CONT'D

WIRE NO.	AWG	COLOR
1	NOT USED	
2	NOT USED	
3	14	BLACK
4	NOT USED	
5	14	BLACK
6	14	RED
7	NOT USED	
8	NOT USED	
9	18	BLACK
10	14	RED
11	NOT USED	
12	14	ORANGE
13	16	BLACK
14	16	RED
15	16	BLACK
16	NOT USED	
17	16	BLACK
18	NOT USED	
19	NOT USED	
20	14	RED
21	14	BLACK
22	16	GREEN
23	16	BLACK
24	16	GREEN
25	NOT USED	
26	18	BLUE
27	NOT USED	
28	16	GREEN
29	NOT USED	
30	NOT USED	


WIRE NO.	AWG	COLOR
31	16	BLACK
32	16	GREEN
33	16	BLUE
34	14	RED
35	16	BLACK
36	16	BLUE
37	NOT USED	
38	NOT USED	
39	NOT USED	
40	16	GREEN
41	16	BLACK
42	NOT USED	
43	NOT USED	
44	16	RED
45	NOT USED	
46	16	BLUE
47	NOT USED	
48	NOT USED	
49	NOT USED	
50	16	RED
51	NOT USED	
52	NOT USED	
53	NOT USED	
54	NOT USED	
55	NOT USED	
56	NOT USED	
57	NOT USED	
58	16	BROWN
59	NOT USED	
60	22	WHITE

WIRE NO.	AWG	COLOR
61	NOT USED	
62	22	ORANGE
63	NOT USED	
64	22	BLUE
65	NOT USED	
66	22	GREEN
67	NOT USED	
68	NOT USED	
69	NOT USED	
70	NOT USED	
71	NOT USED	
72	NOT USED	
73	NOT USED	
74	NOT USED	
75	NOT USED	
76	16	GREEN
77	NOT USED	
78	10	ORANGE
79	NOT USED	
80	10	WHITE
81	NOT USED	
82	16	GREEN



Ref.	Part No.	Serial Number	Description	Qty.
1	613086	(00000000-	) Harness, Main, Drive [2550]	1

WIRE HARNESS, MAIN, 2510




WIRE LIST


WIRE NO.	AWG	COLOR
1	NOT USED	
2	NOT USED	
3	NOT USED	
4	NOT USED	
5	NOT USED	
6	NOT USED	
7	NOT USED	
8	16	RED
9	16	BLACK
10	16	RED
11	NOT USED	
12	NOT USED	
13	16	BLACK
14	16	RED
15	NOT USED	
16	NOT USED	
17	16	BLACK
18	NOT USED	
19	NOT USED	
20	NOT USED	
21	NOT USED	
22	16	GREEN
23	16	BLACK
24	NOT USED	
25	NOT USED	
26	16	GREEN
27	NOT USED	
28	NOT USED	
29	NOT USED	
30	16	GREEN

WIRE NO.	AWG	COLOR
31	16	BLACK
32	16	GREEN
33	16	BLUE
34	14	RED
35	16	BLACK
36	16	BLUE
37	NOT USED	
38	NOT USED	
39	NOT USED	
40	16	GREEN
41	16	BLACK
42	NOT USED	
43	NOT USED	
44	16	RED
45	NOT USED	
46	16	BLUE
47	NOT USED	
48	NOT USED	
49	NOT USED	
50	16	RED
51	NOT USED	
52	NOT USED	
53	NOT USED	
54	NOT USED	
55	NOT USED	
56	NOT USED	
57	NOT USED	
58	16	BROWN
59	NOT USED	
60	NOT USED	

WIRE NO.	AWG	COLOR
61	NOT USED	
62	NOT USED	
63	NOT USED	
64	NOT USED	
65	NOT USED	
66	NOT USED	
67	NOT USED	
68	NOT USED	
69	NOT USED	
70	NOT USED	
71	NOT USED	
72	NOT USED	
73	NOT USED	
74	NOT USED	
75	NOT USED	
76	NOT USED	
77	NOT USED	
78	10	ORANGE
79	NOT USED	
80	10	WHITE
81	NOT USED	
82	16	GREEN




WIRE HARNESS, MAIN, 2510 - CONT'D



Ref.	Part No.	Serial Number	Description	Qty.
1	606539	(00000000-	) Harness, Main, Push [2510]	1

HOUR METER, EMERGENCY STOP AND KEYSWITCH KITS




Ref.	Part No.	Serial Number	Description	Qty.
▽	1	604501	(00000000-) Gauge Kit, Hourmeter [Spdgleams]	1
▲		1010555	(00000000-) Gauge, Hourmeter, 14- 48vdc, Lcd, Rt	1
▲		603081	(00000000-) Wire, 18ga 12.0l Red .25pb /.19qf, Tt	1
▲		604960	(00000000-) Wire, 18ga 09.0l Blk .19pb /.25qf, Tt	1
▲		603080	(00000000-) Wire, 18ga 08.0l Blk .19qf /.19ring, Tt	1
▲		604643	(00000000-) Wire, 18ga 09.0l Blk .19qf /.25qm	1
▽	2	612971	(00000000-) E- Stop Kit [Spdgleam Plus R/S]	1
▲		1011735	(00000000-) Switch, Safety, Shutoff	1
▲		602996	(00000000-) Wire, 16ga 05.0l Red .25qf /.25qf	1
▲		602997	(00000000-) Wire, 16ga 05.0l Red .25qf /.25qm	1
▽	3	612973	(00000000-) Switch Kit, Key [Spdgleam R/S]	1
▲▽		607475	(00000000-) Switch, 12a [Keylock]	1
▲▲		607821	(00000000-) Key, Stl, Replmt	1
▲		601222	(00000000-) Wire, 14ga 13.0l Red .25qf /.25qf	2
4	N/A	(00000000-)	(Replaced by 612971)	1

▽ ASSEMBLY

▲ INCLUDED IN ASSEMBLY

LOW VOLT INTERRUPT KIT




	Ref.	Part No.	Serial Number	Description	Qty.
▽	1	604642	(00000000-	) Interrupter Kit, Low Voltage [36v Batt]	1
▲	2	600832	(00000000-	) Gauge, Discharge, Battery, 36vdc [Digit]	1
▲	3	600831	(00000000-	) Lamp, Red, Blk Body, 36vdc W/ Push Nut	1
▲		604641	(00000000-	) Relay Kit, Low Voltage	1
▲		604643	(00000000-	) Wire, 18ga 09.0l Blk .19qf /.25qm	1
▲		604645	(00000000-	) Wire, 18ga 11.0l Green .25pb /.19qf[Mtw]	1
▲		603078	(00000000-	) Wire, 18ga 09.0l Green .19qf /.19ring	1
▲		603080	(00000000-	) Wire, 18ga 08.0l Blk .19qf /.19ring, Tt	1
▲		603081	(00000000-	) Wire, 18ga 12.0l Red .25pb /.19qf, Tt	1
▲		604960	(00000000-	) Wire, 18ga 09.0l Blk .19pb /.25qf, Tt	1
▲		130193	(00000000-	) Terminal Ring #10 22- 18 Rd	1
▲		281004001	(00000000-	) Terminal, Fem .25 22- 18ga Red, F- Ins	1
▲		130040	(00000000-	) Tie, Cable, Nyl, 06.0l .12w	1
▲		610713	(00000000-	) Label, Low Voltage [Textless]	1
▲		130183	(00000000-	) Terminal, Tt, .25fem, 18- 14ga	1
▲		130133	(00000000-	) Terminal, Mal, .25 22- 18ga Red, F- Ins	1

▽ ASSEMBLY

▲ INCLUDED IN ASSEMBLY


AIR INLET GROUP (JAPAN MARKET)



AIR INLET GROUP (JAPAN MARKET)

Ref.	Part No.	Serial Number	Description	Qty.
1	140524	(00000000-	) Nut, Hex, Lock, .25- 20, Kep	1
2	606684	(00000000-	) Stop, Motor	1
3	140016	(00000000-	) Washer, Lock, Split, 0.25, Ss	2
4	363503	(00000000-	) Screw M6x1.0x12 Panphl Ss	2
5	611472	(00000000-	) Plate, Front, Seal	1
6	611492	(00000000-	) Seal, .50, .50w 12.00l, Adh	1
7	611486	(00000000-	) Gasket, 1.00, 3.50id 4.75od, Adh	1
8	611361	(00000000-	) Seal, .50, .50w 07.00l, Adh	1
9	612156	(00000000-	) Plate Air Intake Seperator	1
10	611357	(00000000-	) Gasket, Plt, Air Seperator, .50th, Adh	1
11	611358	(00000000-	) Seal, .50, 01.50w 04.25l, Adh	1
12	611359	(00000000-	) Seal, .50, 01.50w 05.50l, Adh	1
13	612159	(00000000-	) Gasket Actuator	1
14	140825	(00000000-	) Screw, Pan, Phl, 06 X 0.50, Fmg/Ab, Blk	3
15	611473	(00000000-	) Screen, Inlet, Air	1

PARKING BRAKE KIT



Ref.	Part No.	Serial Number	Description	Qty.
▽	604502	(00000000-	) Brake Kit, Parking	1
▲ 1	600634	(00000000-	) Clamp, Brake, Parking	1
▲ 2	603122	(00000000-	) Bracket, Brake [2550]	1
▲ 3	140887	(00000000-	) Screw, Pan, 10- 24 X 0.38, Ss	4
▲ 4	07514	(00000000-	) Washer, Lock, Int, 10, Ss	4
▲ 5	600624	(00000000-	) Label, Parking Brake, Symbol [Tnv]	1

▽ ASSEMBLY

▲ INCLUDED IN ASSEMBLY

